

## Positioner 1436 cPos

### Operating instructions




### Quick commissioning of the GEMÜ cPos 1436:

#### Prerequisites:

- Mounted to the valve
- Air supply, max. 7bar, connected
- Supply voltage 24V DC connected
- Set value and actual value signals need not be present

For correct commissioning proceed as described in the following flow chart:



## CONTENTS

<b>1. SAFETY INSTRUCTIONS</b>	<b>7</b>
1.1. General information	7
1.2. Explanation of symbols and signs	8
1.3. Safety information	8
1.4. Correct use	9
1.5. Information on use in damp conditions	9
1.6. Mounting position	9
1.7. Tools needed for installation and assembly	9
<b>2. MANUFACTURER'S INFORMATION</b>	<b>10</b>
2.1. Supply	10
2.2. Function	10
2.3. Safety function	10
<b>3. SCHEMATIC DIAGRAM OF THE INPUTS AND OUTPUTS</b>	<b>11</b>
<b>4. MECHANICAL MOUNTING</b>	<b>12</b>
4.1. Mounting to linear actuators	12
4.1.1. Preparation of the valve actuator	12
4.1.2. Mounting the travel sensor	12
4.1.3. Mounting the positioner	12
4.2. Mounting to quarter-turn actuators	13
4.2.1. Preparation of the valve actuator	13
4.2.2. Mounting the travel sensor	13
4.2.3. Mounting the positioner	13
4.2.4. Checking the mounted assembly	14
4.3. External mounting to linear and quarter-turn actuators	14
4.3.1. Preparation of the valve actuator	14
4.3.2. Mounting the travel sensor	14
4.3.3. Checking the mounted assembly	14
4.3.4. Mounting the mounting bracket	14
4.3.5. Connecting the travel sensor	14
<b>5. PNEUMATIC CONNECTIONS</b>	<b>15</b>

<b>6. ELECTRICAL CONNECTIONS</b>	<b>15</b>
6.1. Connection assignment of M12 plug for external travel sensor	16
6.2. Supply voltage	16
6.3. Set value input (only effective for AUTO operating mode)	16
6.4. Actual value input (sensor signal when operating as a process controller)	16
6.5. Actual value output	17
6.6. Outputs	17
6.7. Digital inputs	18
6.7.1. Use of actual value input and set value input as digital inputs	18
6.8. Digital inputs (optional)	19
6.9. RS232 interface	20
<b>7. OPERATION</b>	<b>21</b>
7.1. Operating and display elements	21
7.2. Menu levels	21
7.2.1. Working level	21
7.2.2. Configuration level	22
<b>8. CHANGING PARAMETERS</b>	<b>22</b>
<b>9. COMMISSIONING</b>	<b>23</b>
9.1. General information	23
9.2. Initial commissioning without factory setting	23
9.2.1. Automatic initialisation	24
9.2.2. Manual initialisation	25
9.2.3. Initialisation parameters	26
9.3. Initial commissioning with factory setting	27
<b>10. OPERATING MODES</b>	<b>28</b>
10.1. Operating mode selection	28
10.2. Automatic operation (A:)	28
10.3. Manual operation (M:)	28
10.4. Pause mode (OFF)	28

<b>11. CONFIGURATION MENU (SETUP)</b>	<b>29</b>
11.1. Changes in the configuration menu	30
11.2. Access authorisation in the configuration menu	30
11.3. MENU STRUCTURE 1. SERVICE	31
11.4. MENU STRUCTURE 2. SETBASICS	32
11.5. MENU STRUCTURE 3. SETFUNCTION	33
11.6. MENU STRUCTURE 4. SETCALIBRATION	34
<b>12. PARAMETER TABLE</b>	<b>35</b>
<b>13. EXPLANATION OF PARAMETERS</b>	<b>38</b>
13.1. 1 Service	38
13.1.1. Scanning the input and output signals	38
13.1.2. Activating or deactivating the user access	40
13.1.3. Reading out, deleting and deactivating error messages	42
13.1.4. Display of series number, software release and ID	42
13.2. 2 SetBasics	43
13.2.1. Definition of actual value and set value inputs	43
13.2.2. Reset	43
13.2.3. Initialisation	43
13.2.4. Making the display settings	44
13.3. 3 SetFunction	45
13.3.1. Setting the process controller parameters (optional)	45
13.3.2. Setting the positioner parameters	46
13.3.3. Setting the dead zone	47
13.3.4. Setting the optional digital input parameters	48
13.3.5. Setting output functions and switch points	49
13.3.6. Setting the error time and error action	50
13.3.7. Storing parameter sets	50
13.4. 4 SetCalibration	51
13.4.1. Determining the direction of actual value and set value	51
13.4.2. Defining the characteristics of the control curve	52
13.4.3. Defining the direction of the travel sensor	52
13.4.4. Defining the actual value output signal	52
13.4.5. Determining switch points for error monitoring	53
13.4.6. Scaling the actual value and set value display	53
<b>14. POSITIONER STRUCTURE CPOS 1436</b>	<b>55</b>
<b>15. ERROR MESSAGES</b>	<b>55</b>

<b>16. ABBREVIATED INSTRUCTIONS</b>	<b>56</b>
16.1. Changing the set value signal and actual value signal	56
16.2. Switching the process controller on or off (optional)	56
16.3. Changing the control parameters (Proc P, Proc I, Proc D and Proc T)	57
<b>17. GENERAL INFORMATION REGARDING CONTROL TECHNOLOGY</b>	<b>58</b>
17.1. The control circuit	58
17.2. Control technology terminology	58
17.3. Control parameters	59
17.4. Adaptation of the positioner to the controlled system	60
17.5. Differential equation for the cPos 1436	61
17.6. Effects of the control parameters on the control system	62
17.7. Control characteristics and transitory responses	63
<b>18. TABLE FOR CHANGES TO THE FACTORY SETTINGS</b>	<b>64</b>
18.1. Changed control parameters	64
18.2. Set values for the freely programmable characteristic curve	66
<b>19. TECHNICAL DATA</b>	<b>67</b>
<b>20. ACCESSORIES</b>	<b>67</b>
<b>21. APPLICATION EXAMPLES</b>	<b>68</b>
<b>22. LIST OF TERMS</b>	<b>69</b>



# Operating instructions for Intelligent Positioner 1436 cPos

## 1. Safety instructions

Please read the following safety instructions carefully and observe them!

### 1.1. General information

Important requirements to ensure the perfect function of this GEMÜ 1436 cPos :

- Proper transport and storage
- Installation and commissioning by trained staff
- Operation according to these operating instructions
- Correct maintenance

**The GEMÜ 1436 cPos must be used according to these directions. All information in these operating instructions regarding operation, servicing and maintenance must be observed and applied. If the information is not observed, the operator's guarantee rights and the manufacturer's legal liability cease. The manufacturer shall undertake no responsibility for the GEMÜ cPos 1436 if these safety instructions are not fulfilled.**

Therefore, you must observe:

- the contents of these operating instructions
- the relevant safety regulations for the installation and operation of electrical systems
- that this device must not be used in explosion-endangered areas.

The regulations, norms and guidelines named in these instructions are only applicable in Germany. If the GEMÜ 1436 cPos is used in other countries, the local regulations must be observed. When dealing with harmonised European norms, standards and guidelines, these apply within the Single European Market, the operator must also adhere to national rules if applicable.

The descriptions and instructions in these safety instructions refer to the standard design. The safety instructions do not take into account

- coincidences and events that may occur during assembly, operation and servicing
- local safety regulations which must be adhered to by the operator - also with respect to any additional assembly personnel

If you have any questions, please do not hesitate to ask your closest GEMÜ sales office.

### 1.2. Explanation of symbols and signs

Important information is identified in these operating instructions by the following symbols:



Danger

This symbol indicates danger.  
There is **danger to life or health of persons**  
and/or **considerable material damage** can occur,  
if the instructions given here are not followed.



**Slight bodily injury** and **material damage** can occur, if the safety  
instructions given in connection with this symbol are not observed.



This symbol indicates notices which give important information regarding  
your GEMÜ 1436 cPos.

### 1.3. Safety information



Danger

- Only qualified and trained staff should assemble, electrically connect and commission the GEMÜ 1436 cPos.  
Use qualified staff for operation, servicing, inspection and assembly.  
The areas of responsibility should be defined precisely and the monitoring of the staff and their competence carried out by the operator.  
Train staff that have insufficient knowledge or, if necessary, have them trained by the manufacturer / supplier of the GEMÜ 1436 cPos on order by the operator.  
Ensure that all staff understand the safety instructions.
- Ensure the electrical safety of the host devices.
- Ensure that the electrical values are correct.

If the safety instructions are disregarded then persons, the environment and GEMÜ 1436 cPos may be endangered. Furthermore, failure to observe the safety instructions may lead to a complete loss of claims rights.

**Adhere to legal regulations!**



#### **1.4.    *Correct use***

The GEMÜ 1436 cPos is suitable for use according to the data sheet.

In order to obtain correct product function, the following instructions should be observed and the information on the product labels must also be complied with.

If these instructions and the general operating instructions are not observed, the guarantee for the GEMÜ 1436 cPos and the legal liability expires.

The GEMÜ 1436 cPos serves solely as a positioner and process controller and must be used according to the data sheet.

Any other or additional use is regarded as contrary to regulations and GEMÜ shall not be liable for any consequential damage. The user carries sole risk.

Please pay attention to the pertinent technical safety regulations when planning both the use and operation of the device. The designer, plant constructor or operator is always responsible for positioning and installation of the GEMÜ 1436 cPos.

#### **1.5.    *Information on use in damp conditions***

The following information is intended to help when assembling and operating the GEMÜ 1436 cPos in damp conditions.

- Lay cables and and pipework so that condensate and rain water that remains on the pipework/cables cannot enter the cable glands of the M12 plugs of the GEMÜ 1436 cPos.
- All cable glands of the M12 plugs and fittings must be checked for tightness.



The GEMÜ 1436 cPos 6 may not be cleaned with a high pressure cleaning device because the protection class IP65 is not sufficient for this.

#### **1.6.    *Mounting position***

The mounting position of the GEMÜ 1436 cPos is optional. When mounted upside down it must be ensured that no liquids or dirt can enter the outlet of the pressure relief valve.

#### **1.7.    *Tools needed for installation and assembly***

The tools needed for installation and assembly are not included in the scope of delivery.

## 2. Manufacturer's Information

### 2.1. Supply

Check whether the equipment is complete and undamaged immediately after receipt.

The items in the delivery are detailed in the shipping documents.

Use the order numbers to check whether the type and scope has been delivered as ordered.

If the GEMÜ 1436 cPos positioner is ordered as a complete unit with a valve, these parts and the accessories belonging to them are supplied ready assembled and factory set.

The GEMÜ positioner is then ready for immediate operation.

### 2.2. Function

The GEMÜ 1436 cPos is an intelligent electropneumatic positioner that can be attached to pneumatic actuators. It can be operated as a positioner or a process controller depending on the design.

Normally the GEMÜ 1436 cPos is attached directly to the actuator. The travel sensor is already integrated in the positioner (the GEMÜ 1436 cPos can be optionally ordered with an M12 cable plug for the external attachment of the travel sensor).

The travel sensor measures the current valve position and registers it to GEMÜ 1436 cPos electronics. It compares the actual valve value with the preset set value and readjusts it if it varies too much from the standard tolerance.

If the positioner is ordered with an additional process controller (optional), a current actual value signal (e.g. level, pressure, temperature, flow) is evaluated and the positioner adopts the function of a process controller.

The information required can be called-up on the two-line display of the GEMÜ 1436 cPos. Self-explanatory help texts that explain the meaning of the parameters called-up are also displayed.

The GEMÜ 1436 cPos is operated using four keys.

### 2.3. Safety function




The GEMÜ 1436 cPos has a safety function which ensures that the outlets are vented during a pneumatic and electrical power supply failure.

This safety function, however, is not a substitute for necessary plant-specific safety facilities.

The GEMÜ 1436 cPos is not a safety control system.

### 3. Schematic diagram of the inputs and outputs



## 4. Mechanical mounting

### 4.1. Mounting to linear actuators

#### 4.1.1. Preparation of the valve actuator


- The actuator must be in the zero position (actuator vented).
- Should there be an optical position indicator in the actuator (a red spindle), it must be removed.

#### 4.1.2. Mounting the travel sensor



**Warning: Damage to the spindle surface may lead to failure of the travel sensor!**

- Pull out the spindle of the travel sensor up to the limit stop
- Push the spring over the spindle
- Fix the spindle at point "a"  
**(the spindle must not be damaged during this process)**
- Screw the operating bush onto the spindle




#### 4.1.3. Mounting the positioner

- Place the positioner (1) onto the actuator and fix it to the travel sensor (3) using a suitable M27 wrench.



The positioner must not be fixed by turning the housing as this may result in the danger of overturning the internal stop.


**If correctly mounted to the valve, the positioner can be turned 370° (before hitting an internal stop)**



## 4.2. Mounting to quarter-turn actuators


### 4.2.1. Preparation of the valve actuator

- The actuator must be in the zero position (actuator vented).  
Double acting actuators should be moved to the valve closed position.
- Remove the screw (1) which retains the optical position indicator
- Check turn direction of the actuator



### 4.2.2. Mounting the travel sensor


- Before mounting the travel sensor to the actuator, make sure that the shaft height and the hole pattern in the actuator match the dimensions of the mounting bracket (1).
- The potentiometer shaft is marked.  
If this marking is exactly positioned at the cable exit, the potentiometer is in mid position.
- The potentiometer range is 45° left and right of the mid position.



### 4.2.3. Mounting the positioner


- Place the adapter (3) on the shaft of the potentiometer
- Turn the adapter to the position 0°
- Place the positioner with the travel sensor and mounting bracket on the actuator.
- The adapter lug (2) must engage in the actuator shaft groove.
- The turn direction of the actuator must be the same as that of the travel sensor.
- Attach the mounting bracket (1) to the actuator with the enclosed screws.



View X



#### **4.2.4.      *Checking the mounted assembly***

- Connect the positioner to power and air supply (see page 15)
- The following message is displayed:



The mounted actuator can be moved to the OPEN and CLOSED positions using the  and  keys.

The displayed valve position must be between 0% and 100% .  
If the displayed valve position is not within the range of 0% and 100%, the mechanical mounting must be checked again.

### **4.3.      *External mounting to linear and quarter-turn actuators***

#### **4.3.1.      *Preparation of the valve actuator***

Please refer to chapters 4.1.1. and 4.2.1.

#### **4.3.2.      *Mounting the travel sensor***

Please refer to chapters 4.1.2. and 4.2.2.

#### **4.3.3.      *Checking the mounted assembly***

Please refer to chapters 4.2.4

#### **4.3.4.      *Mounting the mounting bracket***

- Push the positioner connection adapter through the hole in the mounting bracket and attach it with the enclosed nut.
- Use the bolt holes and appropriate fixings to attach the mounting bracket securely.



**Ensure adequate stability of the base used for attachment.  
The positioner must be protected against mechanical stress by the operator.  
Do not use the positioner as a climbing support.**

#### **4.3.5.      *Connecting the travel sensor***


The 5 pin M12 travel sensor plug must be connected to the 5 pin positioner socket.

### 5. Pneumatic connections

- Make the connection between pneumatic positioner outlet A1 (single acting) or A1 and A2 (double acting) and the pneumatic actuator air control inlet.
- Connect the control air supply (additional air) to the air supply connection (1) (max. 7 bar)



Caution: observe max. actuator control pressure!




Connection	Description
1	Air supply connection
3	Venting connection G1/8 with a silencer
V1	Additional air throttle for A1
V2	Outgoing air throttle for A1
V3	Outgoing air throttle for A2
V4	Additional air throttle for A2
V5	Non-return valve
2	Working connection for process valves c.f. 1 and 2 (A1)
4	Working connection for process valve c.f. 3 (A2)

**All pneumatic connections are G1/8**

### 6. Electrical connections



- Connect analogue input (set value input) 0/4-20mA to plug X3.
- Connect supply voltage 24V DC to plug X1.
- If operating as a process controller, connect analogue input (actual value input) 0/4-20mA to plug X3.



Connection	Pin	Signal name
X1 M12 Plug A coding	1	Uv, 24VDC Supply voltage
	2	Make-contact, output K1, 24VDC
	3	GND
	4	Make-contact, output K2, 24VDC
	5	Digital input 1 (optional)
Connection	Pin	Signal name
X2 M12 Plug B coding	1	I+, Actual value output
	2	I-, I Actual value output
	3	RxD, Receive Data, RS232
	4	TxD, Transmit Data, RS232
	5	GND, RS232
Connection	Pin	Signal name
X3 M12 Plug A coding	1	I+, Set value input
	2	I-, Set value input
	3	I+, Actual value input
	4	I-, Actual value input
	5	Digital input 2 (optional)

### 6.1. Connection assignment of M12 plug for external travel sensor



Anschluss	Pin	Signalname
X4	1	U +, Potentiometer signal voltage plus
M12 Socket	2	U -, Potentiometer signal output
A coding	3	U -, Potentiometer signal voltage minus
	4	n.c.
	5	n.c.

### 6.2. Supply voltage

Plug	Pin	Signal name	Wiring
X1	1	24V DC supply voltage	
X1	3	GND	

### 6.3. Set value input (only effective for AUTO operating mode)


Plug	Pin	Signal name	Wiring
X3	1	I+ , set value input	
X3	2	I - , set value input	

### 6.4. Actual value input (sensor signal when operating as a process controller)


Plug	Pin	Signal name	Wiring
X3	3	I+ , actual value input	
X3	4	I - , actual value input	



## 6.5. Actual value output

Plug	Pin	Signal name	Wiring
X2	1	I+ , actual value output	
X2	2	I- , actual value output	

## 6.6. Outputs

Plug	Pin	Signal name	Wiring
X1	2	Output K1	
X1	3	GND	
X1	4	Output K2	

The output function can be switched from NO (make-contact) to NC (break-contact) using menu item **3 SetFunction – K1 Switch/K2 Switch** (pages 33/49).

### 6.7. Digital inputs


GEMÜ cPos 1436 provides the option of using the actual value and set value inputs as digital inputs under certain conditions.

The wiring information under **6.7.1** only applies when the GEMÜ 1436 cPos is supplied without the optional digital input card.

#### 6.7.1. Use of actual value and set value inputs as digital inputs

The actual value and set value inputs can be used as digital inputs under the following conditions:

Control system	Operating mode	Set value input as digital input "In W"	Actual value input as digital input "In X"
Positioner	AUTO		✓
Positioner	MANUAL	✓	✓
Process controller	AUTO		
Process controller	MANUAL	✓	



In order to address the two digital inputs "In W" and "In X" a resistor ( $R=1.2K\Omega \pm 5\%$ ) must be connected in series with the input according to the wiring diagram. The switching levels are  $> 11mA$  for a High-Signal and  $< 8mA$  for a Low-Signal

#### Special wiring – Use of set value input as digital input "In W"

Plug	Pin	Signal name	Wiring
X3	1	I+ , Set value input	
X3	2	I- , Set value input	

#### Special wiring – Use of actual value input as digital input "In X"

Plug	Pin	Signal name	Wiring
X3	3	I+ , Actual value input	
X3	4	I- , Actual value input	


## 6.8. Digital inputs (optional)

The GEMÜ cPos 1436 has four digital inputs when a digital input card is installed.


It is possible to use the actual value and set value inputs as digital inputs under the following conditions:

Control system	Operating mode	Set value input as digital input "In W"	Actual value input as digital input "In X"
Positioner	AUTO		✓
Positioner	MANUAL	✓	✓
Process controller	AUTO		
Process controller	MANUAL	✓	



### Use of set value input as digital input "In W"

Plug	Pin	Signal name	Wiring
X3	2	I- , Set value input	
X1	3	GND	

### Use of actual value input as digital input "In X"

Plug	Pin	Signal name	Wiring
X3	4	I- , Actual value input	
X1	3	GND	

### Digital inputs 1 and 2



Plug	Pin	Signal name	Wiring
X1	5	Digital input 1	
X1	3	GND	
X3	5	Digital input 2	

### 6.9. RS232 interface

Plug	Pin	Signal name	Wiring
X2	3	RxD; Receive data	
X2	4	TxD, Transmit data	
X2	5	GND	


M12 socket, B-coded, 5-pin

D-SUB connector 9-pin



## 7. Operation

### 7.1. Operating and display elements



### 7.2. Menu levels

The GEMÜ cPos 1436 uses two menu levels. These are the working and configuration levels.

#### 7.2.1. Working level

The GEMÜ 1436 cPos is automatically at this level after the supply voltage is switched on. The menu item **Mode** can be used to select between the operating modes **A (Auto)**, **M (Manual)** and **OFF**.

#### **M (MANUAL):**

If **MANUAL** is selected and operated as a positioner, the valve can be opened and closed manually using the + and – keys.

If **MANUAL** is selected together with operation as a process controller, the set value can be changed manually using the + and – keys.

#### **A (AUTO):**

The positioner is triggered by an external set value signal when using the **AUTO** operating mode.

The positioner also processes an external actual value signal when operated as a process controller.





#### **OFF:**

If **OFF** is selected, the positioner is in pause mode and therefore does not react to signal changes.





### 7.2.2. Configuration level

Various parameters can be set at this level (see parameter table, p. 31) in order to realise optimal adaptation to the application conditions.

## 8. Changing parameters


The keys     are used for the GEMÜ 1436 cPos to select the various menus according to **11. Configuration menu** (page 29).

The changes to the parameters required are made using brackets that are put round the respective parameters.

Use the  or  key to move the cursor onto the respective parameter and change it with the  and the  keys.

### Example:

The operating mode is to be changed from **OFF** to **Auto**.



## 9. Commissioning

- Turn on the pneumatic air control supply (observe maximum control pressure for the positioner and the valve!)
- Switch on the 24V DC power supply [plug X1, pin 1 (+) and pin 3 (-)]
- Specify an analogue set value 0/4-20mA
- Specify an analogue actual value (only when operating as a process controller) 0/4-20mA



If the GEMÜ 1436 cPos is *supplied from the factory ready mounted to a valve, it is already works preset (at a control pressure of 5.5 – 6bar) and therefore ready for operation. Re-initialisation (see page 24) is recommended if the system is operated under a different control pressure.*

### 9.1. General information



In order to be able to make changes to settings and parameters for the GEMÜ 1436 cPos, no parts of the housing need be taken apart or opened!  
All parameter settings remain, even after power failure.

### 9.2. Initial commissioning without factory setting (when supplied without a valve)

After assembly and all electrical and pneumatic connections, the positioner must be initialised.

While doing this, it is possible to choose between **automatic initialisation** and **manual initialisation**.

When connecting the supply voltage, the following message is displayed by GEMÜ 1436 cPos after it has completed a short software check:

NoInit	XX.X%
--------	-------

Use the + and – keys to open and close the valve.

### 9.2.1. Automatic initialisation


The positioner adapts to the valve when automatic initialisation is started. All parameters are automatically scanned.

This procedure can take a few minutes, dependent on the valve.



It may be necessary to close the internal positioner throttles a little (V1 and V2 for single acting actuators and V1, V2, V3 and V4 for double acting actuators) if the actuator volume is very low in order to increase the valve operating time.

**Before commissioning, familiarise yourself with the operation of the GEMÜ 1436 cPos on page 22.**



#### Tip for use:

During automatic initialisation of actuators whose travel is not continuous (i.e. with undefined stops) the end positions cannot be clearly detected. In this case manual initialisation by the operator with sequential movement through the menu (see page 25) should be used.



### 9.2.2. Manual initialisation


When manual initialisation is started, the positioner runs through an initialisation program that is similar to the automatic initialisation. However the different program steps for the manual initialisation must be started and confirmed by the operator using the + key.

- Manual initialisation should only be used if the automatic initialisation does not achieve satisfactory control features.
- The menu items **goClose** and **goOpen** should be carried out several times for very small valve strokes in order to ensure an optimum adaptation of the positioner to the valve.

It may be necessary to close the internal positioner throttles a little (V1 and V2 for single acting actuators and V1, V2, V3 and V4 for double acting actuators) if the actuator volume is very low in order to increase the valve operating time.

- In order to prevent incorrect operation, the parameters from manual initialisation are only accepted when they comply with the requirements for correct function.

**Before commissioning, familiarise yourself with the operation of GEMÜ 1436 cPos on page 22.**



## 9.2.3. *Initialisation parameters*

### **InitValve:**

Automatic or manual initialisation (adaptation of the positioner to the valve) is started.

### **CtrlFn:**

The control function type for the valve can be selected during manual initialisation.

**Auto:** Automatic control function search

**NC:** Control function 1 (normally closed)

**NO:** Control function 2 (normally open)

**DA:** Control function 3 (double acting)

**Boost NC:** Control function 1 (for larger actuators, higher air volume)

**Boost NO:** Control function 2 (for larger actuators, higher air volume)

### **goClose:**

The closed valve position is scanned during initialisation.

It must be started with the **+ key** if initialising manually and then confirmed.

### **goOpen:**

The open valve position is scanned during initialisation.

It must be started with the **+ key** if initialising manually and then confirmed.

### **findFunct:**

(only available for automatic initialisation)

The valve control function and pilot valve configuration are determined.

### **adjTime:**

(only displayed when "goOpen" and "goClose" were carried out)

The minimum operating times for the valve are scanned during initialisation.

These must be started with the **+ key** if initialising manually and then confirmed.

### **findCoefficient:**

(only displayed if "adjTime" was carried out)

The valve is checked for control features at various positions between the end positions.

### 9.3. Initial commissioning with factory setting (positioner delivered mounted to the valve)



*If the GEMÜ 1436 cPos was already fully mounted to a valve in the factory, it is already factory preset and therefore immediately operable. We recommend re-initialisation in order to compensate control pressure differences.  
Please proceed as described in item 9.2.1. on page 24.*

When connecting the supply voltage, the GEMÜ 1436 cPos emits one of the following two messages in its display after a short software check:

A:    w XX.X:   x XX.X

or

M:    w XX.X:   x XX.X

**A:**  
Positioner in automatic mode

**M:**  
Positioner in manual mode




To switch between the operating modes, proceed according to **10. Operating modes** as described on the next page.

### 10. Operating modes

The GEMÜ 1436 cPos uses the operating modes **A: AUTO**, **M: MANUAL** and **OFF**.

#### 10.1. Operating mode selection

Selection of the operating mode and entering the configuration menu is carried out in the following menu.



#### 10.2. Automatic operation (A:)

Automatic operation is the normal operating mode. The initialised positioner reacts to set value changes and adjusts the valve accordingly.

The + and - keys have no function in this operating mode.

When operating the device as a positioner, the display on the top left-hand side is operating mode (A), in the middle the current set value (w) and on the top right-hand side the current valve position (x) as a percentage.

When operating the device as a process controller, the display on the top left-hand side is operating mode (A), in the middle the current set value (w) and on the top right-hand side the current actual value (x) of the externally connected process sensor.

#### 10.3. Manual operation (M:)

In manual operating mode as a positioner, the valve can be opened and closed manually using the + and – keys.

In manual operating mode as a process controller the set value can be changed manually using the + and – keys.

#### 10.4. Pause mode (OFF)

If switched to OFF, the positioner is in pause mode and then does not react to any changes to the input signals.

## 11. Configuration menu (Setup)


Various parameter values of the GEMÜ 1436 cPos can be changed in the configuration menu. The parameter name appears in the top left line of the display and the parameter value on the right.

In order to enable immediate use of the GEMÜ 1436 cPos, the most common values were entered as factory settings.



**The sub-menus which are only required for the process controller are only available for the design with integrated process controller (PA01).**

The relevant sub-menus are highlighted in grey.







The configuration menu consists of five sub-menus with the following functions:


- 1. Service** This menu enables the reading-off of all information regarding the positioner, the connected signals and errors that occur.
- 2. SetBasics** SetBasics is used to set the basic settings for the GEMÜ cPos 1436 such as the initialisation, selection of input signals and resetting to factory settings.
- 3. SetFunction** The special positioner functions are activated or deactivated here and the control parameters set.
- 4. SetCalibration** SetCalibration is used to set the directions of action, characteristic curves, stroke limits and closing limits and error limit values.
- 5. Communication** The different communication options for the GEMÜ cPos 1436 can be set here.

### 11.1. Changes in the configuration menu

Changes can be made to the factory settings according to the menu overview below.

**Before making changes in the configuration menu, familiarise yourself with the operation of the GEMÜ 1436 cPos described on page 22.**

In this case, the small squares     represent the GEMÜ 1436 cPos keys that must be pressed to reach the next menu item or within the menu to the various settings.



### 11.2. Access authorisation in the configuration menu

In order to hinder unwanted changes to the parameter values, the configuration level of the GEMÜ 1436 cPos is secured with three different access codes.


The factory code setting is as follows:

Code 1:      Password **0** (New Code: 1)  
Code 2:      Password **0** (New Code: 2)  
Code 3:      Password **0** (New Code: 3)


After entering the factory codes, these codes can be changed by the operator at any time. The access priorities needed are marked in the configuration menu.

In order to change the access codes, please refer to chapter **13.1.2. Activating or deactivating the user access** on page 40.

### 11.3. MENU STRUCTURE 1. SERVICE




### 11.4. MENU STRUCTURE 2. SETBASICS






### 11.5. MENU STRUCTURE 3. SETFUNCTION



### 11.6. MENU STRUCTURE 4. SETCALIBRATION



## 12. Parameter table

Configuration level	Display	Function	Value range	Default setting
	Mode	Select operating modes	AUTO MAN OFF	AUTO
<b>1 Service</b>	ActiveParaSet	Displays the current active parameter set	P1...P4	P1
	Min-Pot-Max	Displays travel sensor position in percent		
	I w	Value of set value signal in mA		
	I x	Value of actual value signal in mA as a process controller		
	W Proc X	Value of set value signal in relation to actual value signal		
	W Pos X	Comparison of set value and valve position		
	Pot Abs	Travel sensor position		
	ProcCtrlOut	Deviation between set value and actual value (process controller)		
	PosCtrlOut	Deviation between set value and actual value (positioner)		
	In w:x:1:2	Displays the current signals of the digital inputs		
	Relay K1:K2	Displays the current position of the internal outputs		
	Valve	Displays the current position of the internal pilot valves		
	Code	Password entry	0...10000	0
	Logout	Block access	OK	
	New Code:	Release the lowest priority	0...10000	0
	New Code:	Release the medium priority	0...10000	0
	New Code:	Release the top priority	0...10000	0
	Error List	Displays error messages		
	Warnings	Superimpose warnings during operation	ON / OFF	ON
	Errors	Superimpose errors during operation	ON / OFF	ON
	Clear Error List	Delete error list	OK	
<b>2 SetBasics</b>	W-Input	Type of set value signal	4-20mA 0-20mA	4-20mA
	X-Input	Type of actual value signal	4-20mA 0-20mA	4-20mA
	Default	Reset to factory settings	Yes / No	Yes
	Init Valve	Starting initialisation		
	GoClose	Scanning the closed position		
	GoOpen	Scanning the open position		
	AdjTime	Scanning the operating times		
	FindCoefficient	Optimising the control features		
	CalPointQty	Quantity of support points when initialising	1...19	9
	D.Refresh	Time for display refresh	0.1...1.0s	0.1s
	D.light	Setting the display lighting	On Key / On	On Key
	AutoReturn	Time for an automatic return to working level	1...60min	5min
	HelpText	Superimpose the help text	ON / OFF	ON
	HelpLanguage	Text language	D / GB	D

# Operating instructions for Intelligent Positioner 1436 cPos

Configuration level	Display	Function	Value range	Factory setting
<b>3 SetFunction</b>	ProcCtrlMode	Switch process controller on or off	ON / OFF	OFF
	ProcCtrl	Sub-menu for setting process controller parameters		
	Proc-P	KP amplification of the process controller	0.0...100.0	0.5
	Proc-I	KI reset time for the process controller	0.1...999.9s	2.0s
	Proc-D	KD share of the process controller	0.0...100.0	0.0
	Proc-T	Process controller delay time	1...10000ms	1000ms
	Pos P	P amplification of the control parameters	0.0...100.0	1.0
	Pos D	D amplification of the control parameters	0.0...100.0	0.0
	Pos T	Decay time of the D share of the control parameters	1...5000ms	100ms
	MinPos	Lower position for stroke limitation as a control range	0.0...100.0%	0.0%
	MaxPos	Upper position for stroke limitation as a control range	0.0...100.0%	100.0%
	CloseTight	Lower close tight function	0.0...10.0%	0.0%
	OpenTight	Upper close tight function	90.0...100.0%	100.0%
	DeadBand	Permissible control deviation	0.1...25.0%	1.0%
	Digital Input	Sub-menu for setting digital inputs		
	In W	Determines the function of the digital input "In W"	OFF/ON Safe/ON ParmSetB0 ParmSetB1	OFF
	In X	Determines the function of the digital input "In X"	OFF/ON Safe/ON ParmSetB0 ParmSetB1	OFF
	In 1	Determines the function of the digital input "In 1"	OFF/ON Safe/ON ParmSetB0 ParmSetB1	OFF
	In 2	Determines the function of the digital input "In 2"	OFF/ON Safe/ON ParmSetB0 ParmSetB1	OFF
	K1 Switch	Defines the type of relay function	NC / NO	NO
	K1 Fn	Determines the function of relay K1	P min P max P min/max W min W max W min/max X min X max X min/max Active Error	no

Configuration level	Display	Function	Value range	Factory setting
	K2 Switch	Defines the type of relay function	NC / NO	NO
	K2 Fn	Determines the function of relay K 2	P min P max P min/max W min W max W min/max X min X max X min/max Active Error	no
	Error Time	Determines the delay time between error recognition and error message	0.5...100.0s	0.2s
	ErrorAction	Determines the function of the process valve if there is an error message	Close/Open/Hold	Close
	AlarmMaxK1	Trigger threshold that switches after K1 is exceeded	0.2...99.8%	10.0%
	AlarmMinK1	Trigger threshold that switches after K1 is undershot	0.2...99.8%	90.0%
	AlarmMaxK2	Trigger threshold that switches after K2 is exceeded	0.2...99.8%	10.0%
	AlarmMinK2	Trigger threshold that switches after K2 is undershot	0.2...99.8%	90.0%
	CpyParamSet	Copies parameters to various working memories (P1/P2/P3/P4)		

Configuration level	Display	Function	Value range	Factory setting
<b>4 SetCalibration</b>	X-Direction	Sets the direction of the actual value signal (rising/falling)	rise / fall	rise
	W-Direction	Sets the direction of the set value signal (rising/falling)	rise / fall	rise
	W-Function	The control curve is defined	lin./1:25/1:50/free	lin.
	Set W-free	10 control curve points can be programmed as desired	W 0% 0...100% W10% 0...100% W20% 0...100% W30% 0...100% W40% 0...100% W50% 0...100% W60% 0...100% W70% 0...100% W80% 0...100% W90% 0...100% W100% 0...100%	0.0% 10.0% 20.0% 30.0% 40.0% 50.0% 60.0% 70.0% 80.0% 90.0% 100.0%
	Y-Direction	Determines the direction of the process controller output (rising/falling)	rise / fall	rise
	PotDir	Defines the direction of the actual value potentiometer of the valve	rise / fall	rise
	OutMinPos	Actual value output at 0/4mA	0.0...100.0%	0.0%
	OutMaxPos	Actual value output at 20mA	0.0...100.0%	100.0%

Configuration level	Display	Function	Value range	Factory setting
	I Min W	Switch-off limit for cable break recognition of the set value	0.0...22.0 mA	3.5 mA
	I Max W	Switch-off limit for excess current recognition of the set value	0.0...22.0 mA	20.5 mA
	I Min X	Switch-off limit for cable break recognition of the actual value	0.0...22.0 mA	3.5 mA
	I Max X	Switch-off limit for excess current recognition of the actual value	0.0...22.0 mA	20.5 mA
	Scaling	Sub-menu for scaling the actual value and set value display		
	Scale	Switching on the scaled display	ON / OFF	OFF
	Decimalpoint	Determines the decimal points displayed	0...2	1
	4mA△	Defines the display which corresponds to a 0/4mA signal		0 %
	20mA△	Defines the display which corresponds to a 20mA signal		100 %


## 13. Explanation of parameters

### Mode:

It is possible to choose between the operating modes **AUTO (A:)**, **MANUAL (M:)** and **OFF** (Pause mode).

### 13.1. 1 Service

#### 13.1.1. Scanning the input and output signals



### ActiveParaSet

Displays the current active memory which is read off. This memory can be changed using the parameter **CpyParaSet** (page 50).

### min – Pot – max:

Displays the minimum and maximum travel sensor position in percent. For perfect operation, this value must lie between 2% and 98%.

**I w:**

Displays the value of the current set value signal in mA

**I x:**

Displays the value of the current actual value signal (when operated as a process controller)

**W Proc X:**

Displays the value of the current set value signal compared to the current actual value signal (when operated as a process controller)

**W Pos X:**

Displays the value of the current set value signal compared to the current valve position in %.

**Pot Abs:**

Displays the current travel sensor position (**Caution, this value may be different to the Pos x value as the valve does not make full use of the full 0-100% range of the travel sensor**).

**Valve:**

Displays the current position of the internal pilot valves (● = valve open).

**Proc Ctrl Out:**

Displays the deviation between set value and actual value (when operated as a process controller).



If the deviation is too large, this is shown by a dot on the left-hand side or right-hand side of the display. In this case, the positioner can no longer work. All parameters on the control system route must be checked.

**Pos Ctrl Out:**

Displays the deviation between set value and actual value (when operated as a positioner).



If the deviation is too large, this is shown by a dot on the left-hand side or right-hand side of the display. In this case, the positioner can no longer work. All parameters on the control system route must be checked.


**In w:x:1:2**

Displays the current conditions of the digital inputs (● = High signal) .

**Relay:**

Displays the current position of the internal relays K1 and K2 (● = Relay switched) .

### 13.1.2. Activating or deactivating the user access



The configuration level of the GEMÜ 1436 cPos is protected in certain areas by various codes against improper changing of parameters. All menu items are marked by symbols indicating their write and read protection.

Example

r0w2

Inp x-Sig: 4-20 mA	
+    -	0-10 V
+    -	0-20 mA

The following symbols are used for this purpose:

**r0** : no release required for reading

**w0** : no release required for writing

**r1** : lowest priority release code 1 required for reading

**w1** : lowest priority release code 1 required for writing


**r2** : medium priority release code 2 required for reading

**w2** : medium priority release code 2 required for writing

**r3** : top priority release code 3 required for reading

**w3** : top priority release code 3 required for writing

The codes can be changed or activated in the following menu:





**Code:**

Enter code for user access. The currently released code is displayed at Active Level .  
e.g. In **Active Level 0** the controller is disabled in all three user levels.

Only the parameters marked by the symbol **r0w0** can be read and changed.

**Logout:**

Serves to log out of write protected and read protected areas in the menu. This function disables various menus depending on the user level activated.

User level 0 is displayed in parameter **Active Level**.

**NewCode1:**

Enter the new code for the lowest user level (user level 1) (factory setting 0).

**NewCode2:**

Enter the new code for the medium user level (user level 2) (factory setting 0).

**NewCode3:**

Enter the new code for the top user level (user level 3) (factory setting 0).



**Factory setting 0 means that all three codes are assigned 0. This means that all parameter menus are released.**

**e.g.:** If user level 2 is to be disabled, user level 2 and also user level 3 must be assigned a code.




**During activation or deactivation of the codes via the RS232-interface other codes can be assigned in the same way as the direct input of codes via the GEMÜ cPos 1436 keypad.**

**This ensures specific disabling of the use of the positioner either directly via the positioner or via the RS232-interface depending on the type of operation.**

**The codes for operation via the RS232-interface can only be assigned, activated or deactivated via the RS232-interface. The codes for direct operation via the GEMÜ cPos 1436 keypad can only be assigned, activated or deactivated via the keypad on the unit itself.**

### 13.1.3. Reading out, deleting and deactivating error messages



#### ErrorList:

The positioner stores all error messages in this menu.

#### hrs:

The positioner operation hours are counted here.

#### Warnings:

The warning messages can be masked or displayed.

The positioner continues normal operation when a warning is given.

Messages are stored in the **Error List** (see error list page 55)

#### Errors:

Error messages can be hidden or displayed.


The positioner goes to the error mode when there is an error message and moves to the position defined under **Error Action**.

Messages are stored in the **Error List**. (see error list page 55)

#### ClearErrorList:

Use + to delete the positioner error list.

### 13.1.4. Display of series number, software release and ID



#### V:X.X.X.X:

Displays the current software release.


#### ID:

Displays the network address.

#### S/N:

Displays the positioner series number.

### 13.2. 2 SetBasics



#### 13.2.1. Definition of actual value and set value inputs

**W-Input:**

Defines the type of set value input signal 0-20mA / 4-20mA / (0-10V optional).

**X-Input:**

Defines the type of actual value input signal 0-20mA / 4-20mA / (0-10V optional).

#### 13.2.2. Reset

**Default:**

Serves to reset the positioner to the factory settings. All values changed by the operator are consequently deleted. An initialisation that has already taken place will also be deleted.

Only the parameter set currently stored in the working memory is reset, however. Stored parameter sets remain unchanged (see page 50).

#### 13.2.3. Initialisation

**InitValve:**

Automatic or manual initialisation (adaptation of the positioner to the valve) is started.

**CtrlFn:**

The type of valve control function can be selected during manual initialisation.

**Auto:** Automatic searching the control function

**NC:** Control function 1 (normally closed)

**NO:** Control function 2 (normally open)

**DA:** Control function 3 (double acting)

**Boost NC:** Control function 1 (for larger actuators, higher air volume)

**Boost NO:** Control function 2 (for larger actuators, higher air volume)

**goClose:**

The closed valve position is scanned during initialisation.

It must be started with the **+** key if initialising manually and then confirmed.

**goOpen:**

The open valve position is scanned during initialisation.  
It must be started with the **+ key** if initialising manually and then confirmed.

**findFnc:**

The valve control function and configuration of the pilot valves are determined.

**adjTime:**

(only displayed when "goOpen" and "goClose" are carried out)  
The minimum operating times for the valve are scanned during initialisation.

**findCoefficient:**

(only displayed if "adjTime" was carried out)  
The valve is checked for control features at various positions between the end positions.

**CalPointQty:**

The quantity of set points when initialising can be changed.  
Example. QtyCalPoint=9 means -> the valve will be examined for control features between the end positions stops in 9 positions (10% steps here).

## **13.2.4.      *Making the display settings***

**D.Refresh:**

The time for display refresh can be changed.

**DLight** (this function is not yet available in the hardware):

The features of the display lighting can be switched between the following settings:  
**OnKey** – Display lighting is activated by pressing a key. The display lighting remains activated after the last key is pressed for the period set using **AutoReturn**.  
**On** – The display lighting is permanently activated.

**AutoReturn:**

The time for the automatic return to the working level after last activating a key can be set.  
This time setting is also effective for the display lighting (**DLight**).


**HelpText:**

The help texts that appear as a default in the second line of the display can be masked.  
If the help texts are masked, the key assignment is displayed.

**HelpLanguage:**

The text output language may be selected between D-German and GB-English.

### 13.3. 3 SetFunction



#### 13.3.1. Setting the process controller parameters (optional)

This menu is only available for the design with integrated process controller (PA01).

##### **ProcCtrlMode**

Switches the process controller on or off.

##### **ProcCtrl**

Sub-menu for setting process controller parameters. Only available when **ProcCtrlMode** is ON.

##### **Proc-P**

Indicates the KP amplification of the process controller.

##### **Proc-I**

Indicates the T resetting time for the process controller.

##### **Proc-D**

Indicates the KD process controller differential share.

##### **Proc-T**

Indicates the Tv delay time for the process controller. Only available if Proc-D > 0.

**13.3.2.      Setting the positioner parameters****PosCtrl**

Makes parameters available for the positioner.

**Pos P**

Matches the positioner's KP amplification.

The optimum value is determined by the positioner during initialisation.

**Pos D**

Matches the positioner's D amplification.

**Pos T**


Matches the decay time for the positioner's D share.

**MinPos**

Defines the lower position of the control range (serves as a closing limit).

**MaxPos**

Defines the upper position of the control range (serves as a stroke limit).



**OpenTight and CloseTight**


Determines the close tight function areas (complete pressurization or ventilation of the actuator).

With this function the valve can be moved into the seat using the maximum possible actuator force. The close tight function can be activated for one end or both end positions.

Example

If the setting Close tight 0.5% and Open tight 98.5% is made, the valve closes or opens fully according to the following diagram.

The hysteresis is 1%.



If the control characteristic curve (W function page 52) is changed to the values 1:25 or 1:50, the close tight value should be set at  $>2.0$  (if the characteristic curve is 1:50) or  $>4.0$  (if the characteristic curve is 1:25), in order to shut the valve fully.

**13.3.3. Setting the dead zone****DeadBand**

Defines the permissible deviation – dead zone between set value and actual value. Effects both the positioner and the process controller.

## 13.3.4. Setting the optional digital input parameters

### Digital Input:

Sub-menu for setting the digital inputs

### In W:

Defines the functions of the High signal at digital input In W ( connection at set value input, only effective for manual operation).

### In X:

Defines the functions of the High signal at digital input In X ( connection at actual value input, only effective when operating as a positioner)

### In 1: (optional)

Defines the functions of the High signal at digital input 1

### In 2: (optional)

Defines the functions of the High signal at digital input 2

Parameter	Function	Function at Low signal level	Function at High signal level
OFF	Digital inputs deactivated		
OFF/ON	Sets the positioner to the pause mode	<b>OFF:</b> Positioner in pause mode	<b>ON:</b> Positioner active
Safe/ON	Moves the positioner into a safe position	<b>Safe:</b> Positioner moves to the position defined under Error Action	<b>ON:</b> Positioner active
ParmSetB0	Loads parameter sets into working memory	See following table	
ParmSetB1	Loads parameter sets into working memory		

Current signal for ParmSetBO	Current signal for ParmSetB1	Memory which is read out
0	0	P1
0	1	P2
1	0	P3
1	1	P4



**Before loading another parameter set, it has to be loaded to the respective memory (see 13.3.7 CpyParamSet page 50).**



## 13.3.5. *Setting output functions and switch points*

### DigitalOutput

Defines the switch conditions for the internal outputs K1 and K2.

#### K1 Switch

Defines the relay contact type.

NO – make-contact or NC – break-contact

#### K1 fn

Establishes the function of relay K1.

(no)	No function
(P min)	Lower than the alarm position preset under <b>AlarmMinK1</b>
(P max)	Exceeds the alarm position preset under <b>AlarmMaxK1</b>
(P min/max)	Lower or higher than the preset alarm positions
(W min)	Lower than the set value preset under <b>AlarmMinK1</b>
(W max)	Exceeds the set value preset under <b>AlarmMaxK1</b>
(W min/max)	Lower or higher than the preset set value
(X min)	Lower than the actual value preset under <b>AlarmMinK1</b>
(X max)	Exceeds the actual value
(X min/max)	Lower or higher than the actual value
Active	Active if the positioner is in the OFF-mode
Error	Error message

#### AlarmMinK1

Sets the trigger threshold in % under which relay K1 is switched.

#### AlarmMaxK1

Sets the trigger threshold in % over which relay K1 is switched.

#### K2 Switch

Defines the relay contact type.

NO – make-contact or NC – break-contact

#### K2 fn

Determines the function of the relay K2.

(no)	No function
(P min)	Lower than the alarm position preset under <b>AlarmMinK2</b>
(P max)	Exceeds the alarm position preset under <b>AlarmMaxK2</b>
(P min/max)	Lower or higher than the preset alarm positions
(W min)	Lower than the set value preset under <b>AlarmMinK2</b>
(W max)	Exceeds the set value preset under <b>AlarmMaxK2</b>
(W min/max)	Lower or higher than the preset set value
(X min)	Lower than the actual value preset under <b>AlarmMinK2</b>
(X max)	Exceeds the actual value
(X min/max)	Lower or higher than the actual value
Active	Active if the positioner is in the OFF-mode
Error	Error message

## **AlarmMinK2**

Sets the trigger threshold in % under which relay K2 is switched.

## **AlarmMaxK2**

Sets the trigger threshold in % over which relay K2 is switched.

### **13.3.6.      *Setting the error time and error action***

#### **ErrorTime**

Determines the delay between error recognition and error message.

#### **ErrorAction**

Defines the behaviour of the valve if there is an error message and when switching to the **OFF-MODE**.

**Close:** Valve is vented

**Open:** Valve is pressurized

**Hold:** Valve remains in its current position.

### **13.3.7.      *Storing parameter sets***

#### **CpyParamSet**

The current positioner settings can be copied and read out in different memories. It is not possible to load all changed control parameters into the programme memories. Please refer to page 64 for an overview of the parameters which can be stored. If a parameter cannot be stored, it is active in all memories.

(P1<=W)	Write from W to P1
(P1=>P2)	Write from P1 to P2
(P1<=P2)	Read from P2 to P1
(P1=>P3)	Write from P1 to P3
(P1<=P3)	Read from P3 to P1
(P1=>P4)	Write from P1 to P4
(P1<=P4)	Read from P4 to P1
(OFF)	Storage function deactivated

**P1:** Memory 1

**P2:** Memory 2


**P3:** Memory 3

**P4:** Memory 4

**W:** Factory settings

**The GEMÜ 1436 cPos automatically stores all parameters in working memory P1.**

### 13.4. 4 SetCalibration




#### 13.4.1. Determining the direction of actual value and set value

##### X-Direction:

Defines the direction of the actual value signal (rising/ falling).

##### W-Direction:


Defines the direction of the set value signal (rising/ falling).



### 13.4.2. Defining the characteristics of the control curve

#### W-Function:

The characteristics of the control curve can be defined (linear/ 1:25 / 1:50 / free)



In order to be able to close the valve fully at an equal % selection of 1:25 or 1:50, the close tight function (see p. 47) must be set to the value >2.0 (for equal % 1:50) or >4.0 (for equal % 1:25).

#### SetW-free:

Eleven set points on the control curve can be programmed as required.

#### Y-Direction

Defines the direction of the process controller output (rising/falling)

### 13.4.3. Defining the direction of the travel sensor

#### Pot Dir:

The direction of the actual value potentiometer can be defined.

### 13.4.4. Defining the actual value output signal

#### OutMinPos:

Defines the valve position at which an actual value signal of 0/4 mA is emitted at the output.

**OutMaxPos:**

Defines the valve position at which an actual value signal of 20 mA is emitted at the output.

### **13.4.5.      *Determining switch points for error monitoring***

**I Min W:**

Defines the point below which the set value signal activates an error message

**I Max W:**

Defines the point above which the set value signal activates an error message

**I Min X:**

Defines the point below which the actual value signal activates an error message

**I Max X:**

Defines the point above which the actual value signal activates an error message

### **13.4.6.      *Scaling the actual value and set value display***

**Scaling:**

Sub-menu for scaling the actual value and set value display.

**Scale:**

Defines whether the actual and set value display is to be displayed as scaled variable or in percent.

**ON:** Display as scaled variable

**OFF:** Display in percent

**Decimalpoint:**

Determined the displayed decimal points.


**4mA $\Delta$ :**

Defines the value which is displayed when there is a 0/4mA signal .


**20mA $\Delta$ :**

Defines the value which is displayed when there is a 20mA signal.


### Possible setting values for the freely scalable actual and set value inputs:



### Display when Scale OFF is set:




### Display when Scale ON (e.g. mbar) is set:



Changing the scaling values is also directly possible in this menu level by selecting the corresponding parameters.

### 14. Positioner structure cPos 1436




### 15. Error messages

Error no.	Error text	Description	Condition for the occurrence of the error	Error cause
000	NO ERROR	There are no errors		
010	lw < 4mA <b>Error</b>	The set value signal is lower than 4mA	The positioner is in automatic mode	A cable break at the set value input
011	lw > 20mA <b>Error</b>	The set value signal is higher than 20mA	The positioner is in automatic mode	The set value signal is higher than 20mA
012	lx < 4mA <b>Error</b>	The actual value signal is lower than 4mA	The process controller is active	A cable break at the actual value input
013	lx > 20mA <b>Error</b>	The actual value signal is higher than 20mA	The process controller is active	The actual value signal is higher than 20mA
020	Pot wrong dir <b>Error</b>	The potentiometer has recognised the wrong control function during initialisation	Parameter "CtrlFn" is set to AUTO and a valve with control function 3 is recognised, from which the actuator has moved in the wrong direction. Parameter "CtrlFn" is set for a fixed control function. This set control function is not in accordance with the control function determined during initialisation.	The pneumatic connections for "CLOSED" and "OPEN" on the valve have been switched or the parameter "Pot Dir" is set on "fall" The wrong control function is set
021	Wrong function <b>Error</b>	An incorrect control function was recognised during automatic initialisation	Parameter "CtrlFn" is set for a fixed control function. This set control function is not in accordance with the control function determined during initialisation.	The wrong control function is set in the "CtrlFn" parameter. If the parameter is set to AUTO, the 1436 determines the corresponding control function and leaves it there.
030	Air missing <b>Warning</b>	A failure of the compressed air was discovered.	The 1436 tries to change the valve position, but it changes in the wrong direction. <b>Caution:</b> Dependent on the positioner's set value reaction time, the error may be acknowledged in the meantime. It then recurs.	No compressed air.  Failure of the internal pilot valves.


All error messages can be read in the menu item **ErrorList (1 Service/ 1.3 Diagnosis)**. The menu item **ClearErrorList (1 Service/ 1.3 Diagnosis)** can be used to clear the internal error memory.

### 16. Abbreviated instructions

#### 16.1. Changing the set value signal and actual value signal




#### 16.2. Switching the process controller on or off (optional)






### 16.3. Changing the control parameters (Proc P, Proc I, Proc D and Proc T)



## 17. General information regarding control technology

### 17.1. The control circuit



### 17.2. Control technology terminology

#### Reference variable (Set value) w:

The input variable (set value) for the control circuit. The controlled variable x should follow it with a pre-determined dependency.

#### Controlled variable (Actual value) x:

The volume flow currently measured.

#### System deviation $x_d$ :

The difference between reference variable w and controlled variable x,  $x_d = w - x$

#### Correcting variable y:

Input variable for the controlled system. The process controller guidance to the positioner regarding the position in which the triggered control valve must be driven in order to achieve the desired volume flow.

#### Disturbance variable z:

An external variable that influences the controlled system that normally cannot be influenced (e.g. volume flow fluctuations).

### 17.3. Control parameters

#### Explanation of parameters of GEMÜ cPos 1436:

<b>Proc P</b>	→	<b>K<sub>P</sub></b>
<b>Proc I</b>	→	<b>T<sub>n</sub></b>
<b>Proc D</b>	→	<b>K<sub>D</sub></b>
<b>Proc T</b>	→	<b>T<sub>v</sub></b>

#### Proportional range **X<sub>p</sub>**:

The proportional range tells us the extent to which the controlled variable x changes when the correcting variable y is adjusted.

**X<sub>p</sub>** can be used to adapt the positioner amplification to the controlled system.

If a small proportional range is selected, it has a large correcting variable y (e.g. 20mA) as a result, i.e. the positioner reacts more swiftly and harder with a small proportional range. If a too small proportional range is chosen, this leads to oscillation of the control circuit.

#### Proportional correction value **K<sub>p</sub>**:

Instead of the description proportional range, the expression proportional correction value **K<sub>p</sub>** is used frequently.

Conversion of **X<sub>p</sub>** to **K<sub>p</sub>** is:

$$X_p = 100[\%] / K_p \quad \text{or} \quad K_p = 100[\%] / X_p$$

The **K<sub>p</sub>** value tells us to what degree the controlled variable x changes if the correcting variable y is adjusted.

$$K_p = \Delta x / \Delta y = x_2 - x_1 / y_2 - y_1$$

In order to obtain a unit-independent relationship in the equation above, x and y must be divided by their respective maximum values (100%).

In this case, a high **K<sub>p</sub>** value results in smaller deviation. However, if the **K<sub>p</sub>** value is set too high, it leads to an increased tendency for the control circuit to oscillate.

#### Rate time **T<sub>v</sub>**:

It is used to set the intensity of the D share.

#### Differential share (D share):

The D share “brakes” the positioner when starting up to the set value. It can be used to avoid oscillating above and beyond the controlled variable. If the controlled variable is changed, the D share counteracts this change.

For an inverse positioner (heating) this would mean:

- If the controlled variable is reduced due to a disturbance in the controlled system, the D share counteracts the change by creating a positive regulation ratio.
- If the controlled variable increases due to a disturbance in the controlled system, the D share counteracts this change by creating a negative regulation ratio.

The higher the rate time **T<sub>v</sub>** is set, the stronger the dampening reaction.

**Integral share (IShare)  $K_i$ :**

The I share  $K_i$  changes the positioner regulation ratio continuously until the actual value reaches the set value.

The regulation ratio will be integrated upwards or downwards as long as a deviation exists. The influence of the I share will become larger the longer a deviation exists. The shorter the resetting time  $T_n$  and the larger the deviation, the stronger (faster) the effect of the I share.

The I share hinders a constant deviation.

**Resetting time  $T_n$ :**

The resetting time  $T_n$  determines the duration how long a deviation is adjusted.

If a high value is preset for the resetting time  $T_n$ , this means a small influence of the I share and vice-versa.

During the resetting time  $T_n$ , the controlled variable change caused by the P share is added again. Thus there is a fixed relationship between the P share and the I share. If the P share is thus changed, the time response changes too if the  $T_n$  value remains constant.

$$K_i = 1 / T_n$$

## ***17.4. Adaptation of the positioner to the controlled system***

**Optimisation of the positioner:**

In order to achieve good behaviour of the control circuit it is necessary to adapt the positioner to the process.

Good valve behaviour, for instance, can be quick adjustment of maximum power for pre-shooting or non-overshooting-free adjustment of maximum power if the adjustment of power takes longer.

With varying plant conditions, the optimum adjustment parameters must be determined by trial and error through experimentation or rule of thumb.

**The meaning of parameters for the GEMÜ 1436 cPos:**

<b>Proc P</b>	→	<b><math>K_P</math></b>
<b>Proc I</b>	→	<b><math>T_n</math></b>
<b>Proc D</b>	→	<b><math>K_D</math></b>
<b>Proc T</b>	→	<b><math>T_v</math></b>

**Interpretation of the positioner parameters according to Ziegler-Nichols:**

The following process is intended to help to adapt the positioner to the controlled system (however this process can only be implemented on controlled systems where it is possible to let the controlled variable oscillate of its own accord).

- Set the values for **K<sub>p</sub> (Proc P)** and **T<sub>v</sub> (Proc T)** to their minimum and the **T<sub>n</sub> (Proc I)** value to 0 (this leads to the smallest possible effect of the positioner).
- Enter the desired set value manually in manual mode.
- Slowly increase **K<sub>p</sub> (Proc P)** (decrease **X<sub>p</sub>**) until the controlled variable starts to oscillate harmoniously. Ideally the control circuit should be stimulated to oscillate by erratic set value changes during the K<sub>p</sub> adjustment.
- Note the K<sub>p</sub> value thus obtained as a critical proportional correction value, **K<sub>p,krit</sub>**.
- Following this, determine the duration of an oscillation as **T<sub>krit</sub>**. If possible, use a stopwatch to measure several oscillations and use the arithmetic mean as **T<sub>krit</sub>**.
- Use the values thus determined for **K<sub>p,krit</sub>** and **T<sub>krit</sub>** to calculate the missing **K<sub>p</sub>**, **T<sub>n</sub>** and **T<sub>v</sub>** parameters according to the following table.

	<b>K<sub>p</sub> = Proc P</b>	<b>T<sub>n</sub> = Proc I</b>	<b>Proc D</b>	<b>T<sub>v</sub> = Proc T</b>
<b>P</b>	0.50 x K <sub>p,krit</sub>	0	0	0
<b>PI</b>	0.45 x K <sub>p,krit</sub>	0.85 x T <sub>krit</sub>	0	0
<b>PID</b>	0.59 x K <sub>p,krit</sub>	0.50 x T <sub>krit</sub>	0.59 x K <sub>p,krit</sub>	0.12 x T <sub>krit</sub>

- If necessary, re-adjust the **K<sub>p</sub>** and **T<sub>n</sub>** values a little until the control system shows satisfactory behaviour

**17.5. Differential equation for the GEMÜ 1436 cPos**

$$y = \text{ProcP} * \left[ x_d + \frac{1}{\text{ProcI}} * \int x_d \, dt \right] + \text{ProcD} * \left[ \frac{dx_d}{dt} - \text{ProcTv} * \frac{dy}{dt} \right]$$

### **17.6. Effects of the control parameters on the control system**

**Proc P:**

Larger: The positioner reacts quicker, however it tends to oscillate and controls less accurately. The set value is achieved quicker.

Smaller: The positioner controls slower. The set value is achieved slower. Control is more precise.

**Proc D:**

Larger: Control is slower.

Smaller: Set value is achieved quicker.

**Proc I:**


Larger: The positioner reacts slower to actual value changes. Proc I should be increased for actual value sensors with relatively slow output signals.

Smaller: The positioner reacts quicker to actual value changes.

**Proc T:**

Larger: The system deviation has a longer effect although set value = actual value

### 17.7. Control characteristics and transitory responses



## 18. Table for changes to the factory settings

### 18.1. Changed control parameters

Fields marked by X cannot be written into the individual memories but are active for all memories.

Configuration level	Display	Function	P1	P2	P3	P4	Factory settings
<b>1 Service</b>	New Code: 1	Release lowest priority		X	X	X	0
	New Code: 2	Release medium priority		X	X	X	0
	New Code: 3	Release top priority		X	X	X	0
	Warnings	Superimpose warnings during operation					ON
	Errors	Superimpose errors during operation					ON
<b>2 SetBasics</b>	W-Input	Type of set value signal					4-20mA
	X-Input	Type of actual value signal					4-20mA
	CalPointQty	Quantity of set points when initialising					9
	D.Refresh	Time for display refresh		X	X	X	0.1s
	DLight	Setting the display lighting					OnKey
	AutoReturn	Time for automatic return to the working level					5min
	HelpText	Superimpose the help text					ON
	HelpLanguage	Text output language					D
<b>3 SetFunction</b>	ProcCtrlMode	Switch the process controller on or off					OFF
	Proc-P	KP amplification of process controller					0.5
	Proc-I	KI resetting time for the process controller					2.0s
	Proc-D	KD share of the process controller					0.0
	Proc-T	Process controller delay time					1000ms
	Pos P	P amplification of the control parameters					1.0
	Pos D	D amplification of the control parameters					0.0
	Pos T	Decay time of the D share of the control parameters					100ms
	MinPos	Lower position for stroke limitation as a control range					0.0%
	MaxPos	Upper position for stroke limitation as a control range					100.0%
	CloseTight	Lower close tight function					0.0%
	OpenTight	Upper close tight function					100.0%
	DeadBand	Permissible control deviation					1.0%



# Operating instructions for Intelligent Positioner 1436 cPos

Configuration level	Display	Function	P1	P2	P3	P4	Factory settings
	In W	Determines the function of digital input In W		X	X	X	OFF
	In X	Determines the function of digital input In X		X	X	X	OFF
	In 1	Determines the function of digital input In 1		X	X	X	OFF
	In 2	Determines the function of digital input In 1		X	X	X	OFF
	K1 Switch	Defines the type of relay function					NO
	K1 Fn	Determines the function of relay K1					no
	K2 Switch	Defines the type of relay function					NO
	K2 Fn	Determines the function of relay K2					no
	Error Time	Determines the delay time between error recognition and error message					0.2s
	ErrorAction	Determines the function of the process valve if there is an error message					Close
	AlarmMaxK1	Trigger threshold that switches after K1 is exceeded					10.0%
	AlarmMinK1	Trigger threshold that switches after K1 is undershot					90.0%
	AlarmMaxK2	Trigger threshold that switches after K2 is exceeded					10.0%
	AlarmMinK2	Trigger threshold that switches after K2 is undershot					90.0%

<b>4 SetCalibration</b>	X-Direction	Sets the direction of the actual value signal (rising/falling)					rise
	W-Direction	Sets the direction of the set value signal (rising/falling)					rise
	W-Function	The control system curve is defined					lin.
	Y-Direction	Determines the direction of the process controller output (rising/falling)					rise
	PotDir	Defines the direction of the actual value valve potentiometer					rise
	OutMinPos	Actual value output at 0/4mA					0.0%
	OutMaxPos	Actual value output at 20mA					100.0%
	I Min W	Switch-off limit for cable break recognition of the set value					3.5 mA
	I Max W	Switch-off limit for excess current recognition of the set value					20.5 mA
	I Min X	Switch-off limit for cable break recognition of the actual value					3.5 mA
	I Max X	Switch-off limit for excess current recognition of the actual value					20.5 mA
	Scaling	Switches the scaled display on					OFF
	Decimalpoint	Determines the displayed decimal points					1
	4mA=	Defines the display that corresponds to a 0/4mA signal					0 %
	20mA=	Defines the display that corresponds to a 20mA signal					100 %

## 18.2. Set values for the freely programmable characteristic curve

Configuration level	Display	Characteristic curve point	P1	P2	P3	P4	Factory setting
<b>4 SetCalibration</b>	Set W-free						
		0%					0%
		10%					10%
		20%					20%
		30%					30%
		40%					40%
		50%					50%
		60%					60%
		70%					70%
		80%					80%
		90%					90%
		100%					100%

## 19. Technical data

General specifications		Operating conditions	
Protection class acc. to EN 60529	IP 65	Ambient temperature	0 to +60°C
Weight	600 g	Storage temperature	0 to +60°C
Dimensions	see data sheet	Control medium	Air or inert gases, filtered 50µm, lubricated or unlubricated
Electrical specifications		Air supply	1.5 to 7 bar
<b>Supply voltage</b>		Air consumption (when idle)	0 L/min
Supply voltage	U <sub>v</sub> = 24V DC ± 10%	Air output	for Flow rate Code 01 100 L/min for Flow rate Code 02 180 L/min
Current consumption	for Flow rate Code 01 I <sub>typ</sub> = 100mA (@24V DC) for Flow rate Code 02 I <sub>typ</sub> = 140mA (@24V DC)	<b>Travel sensor</b>	For direct mounting
<b>Analogue input signals</b>		<b>Linear version</b>	
Set value	0/4 – 20mA	Stroke	0-30 / 0-50 / 0-75 mm
Actual value	0/4 – 20mA	Resistance	3 / 5 / 5 kΩ
External travel sensor	R <sub>g</sub> 1-10kΩ	Minimum stroke	≤ 8% of the stroke length
<b>Digital input signals</b>		<b>Quarter turn version</b>	
Voltage	24V DC	Angle of turn	0-93°
<b>Analogue output signals</b>		Resistance	3 kΩ
Position indication	4 – 20mA		
<b>Digital output signals</b>			
2 relay outputs	24V DC		
Current	≤ 0.5 A		

## 20. Accessories – Connection set

Field bus	Code	Connection X2, B coding	Code
Connection set	S01	without connector socket, with M12 protection cap	0000
<b>Accessories</b>	<b>Code</b>	M12 female angled connector B coding, screw terminal	00M0
	Z	M12 female angled connector B coding, screw terminal for Profibus DP	DPM0
<b>Connection X1 and X3, A coding</b>	<b>Code</b>	Y cable + 1 x M12 female angled connector B, screw terminal	00Y0
without connector socket, with M12 protection cap	0000	Y cable + 1 x M12 female angled connector B, with 5m PUR cable, 0,34mm <sup>2</sup> and 5m SUB-D connecting cable	05Y0
M12 female angled connector A coding, screw terminal	00M0	Y cable + 1 x M12 female angled connector B, with 10m PUR cable, 0,34mm <sup>2</sup> and 10m SUB-D connecting cable	10Y0
M12 female angled connector A coding, adapter cable A/B coding for Profibus DP	DPM0		
M12 female angled connector A coding, with 5m PUR cable, 0.34mm <sup>2</sup>	05M0		
M12 female angled connector A coding, with 10m PUR cable, 0.34mm <sup>2</sup>	10M0		


Order example	1219	S01	Z	0000	0000
Type	1219				
Field bus		S01			
Accessories			Z		
Connection X1 and X3, A coding				0000	
Connection X2, B coding					0000

### 21. Application examples




#### cPos 1436 as process controller + two-wire transmitter

cPos 1436 Intelligenter Stellungsregler  
Intelligent positioner



#### cPos 1436 as process controller + four-wire transmitter

cPos 1436 Intelligenter Stellungsregler  
Intelligent positioner



## 22. List of terms

### A

Abbreviated instructions	55
Accessories	66
Actual value input	15
Actual value output	15
System deviation	57
Additional air throttle	15
Additional air throttle A1	15
adjTime	34, 43
Air missing	54
Air supply connection	15
AlarmMaxK1	36, 48
AlarmMaxK2	36, 49
AlarmMinK1	36, 48
AlarmMinK2	36, 49
Application examples	67
Auto	26, 42
Automatic initialisation	23
Automatic operation	27

### B

Boost NC	42
Boost NO	42

### C

CalPointQty	34, 43
Clear Error List	34, 40
CloseTight	35, 46
Code	40
Code	34
Reference variable	57
Commissioning	22
Communication	28
Configuration level	21
Configuration menu	21, 28, 29
control pressure	15, 22
Control system structure	54
Manipulated variable	57
CpyParamSet	36, 49
CtrlFun	42

### D

D.Refresh	34, 43
-----------	--------

DA	42
DeadBand	35, 46
Decimalpoint	37, 52
Default	34, 42
Diagnosis	40
Differential equation	60
Differential share	58
Digital Input	35, 47
Digitaleingänge	18
DigitalOutput	48
Disturbance variable	57

### E

Electrical connections	15
Error List	34, 40
Error messages	54
ErrorAction	36, 49
Errors	34, 40
ErrorTime	36, 49
Explanation of parameters	37

### F

findCoefficient	34, 43
findFnct	43
Function	10

### G

Gemü specific	41
goClose	34, 43
goOpen	34, 43

### H

HelpLanguage	34, 44
HelpText	34, 43
hexagonal nut M27	12
hrs	40

### I

I Max W	37, 52
I Max X	37, 52
I Min W	37, 52
I Min X	37, 52
I w	34, 38

I x	34, 38
I/O-Status	37
ID	41
In 1	35, 47
In 2	35, 47
In W	35, 47
IN W X 1 2	38
In X	35, 47
Init Valve	34, 42
Integral share	59

### K

K1 Fn	35, 48
K1 Switch	35, 48
K2 Fn	36, 48
K2 Switch	36, 48

### L

Login	39
Logout	34, 40

### M

Manual	26
MANUAL	20
Manual initialisation	24
Manual operation	27
Manufacturer's Information	10
MaxPos	35, 45
Menu management cPos	21
Menu structure 1. Service	30
Menu structure 2. SetBasics	31
Menu structure 3. SetFunction	32
Menu structure 4. SetCalibration	33
MinPos	35, 45
Min Pot Max	34, 37
Mode	20, 34, 37

### N

NC	42
New Code	34, 40
New Code	34
NO	42
NO ERROR	54
Non-return valve	15

### O

OpenTight	35, 46
Operation	20
Operation modes	27
Optimisation of the positioner	59
Outgoing air throttle	15
Outgoing air throttle A1	15
OutMaxPos	36, 52
OutMinPos	36, 51
Control parameters	58
Controlled variable	57

### P

Parameter table	34
Pause mode	27
Pneumatic connections	15
Pos D	35, 45
Pos P	35, 45
Pos Tv	35, 45
PosCtrlOut	34, 38
Positioner	27
Pot Abs	34, 38
Pot wrong dir	54
PotDir	36, 51
ProcCtrl	35, 44, 45
ProcCtrlMode	35, 44
ProcCtrlOut	34, 38
Proc-D	35, 44
Process operation level	20
Proc-I	35, 44
Proc-P	35, 44
Proc-T	35, 44
Proportional correction value	58
Proportional range	58

### R

Rate time	58
Regelparameter	58
Relay	38
Relay	34
relay output	15
Reset	42
Resetting time	60
RS232	15

**S**

S/N	41
Safety function	10
Scale	37, 52
Scaling	37, 52
Service	28, 30, 37
Set value input	15
Set W-free	36, 51
SetBasics	28, 31, 42
SetCalibration	28, 33, 50
SetFunction	28, 32, 44
Sicherheit	8
Safety instructions	7
Supply	10

**T**

Technical data	66
Terminal X1	15
Terminal X2	15
Terminal X3	15
Transitory responses	62

**V**

Valve	34, 38
Venting connection	15

**W**

W Direction	36
W Function	36
W Pos x	34, 38
W Proc X	34, 38
Warnings	40
W-Direction	50
W-Function	51
W-Input	34, 42
Working connection A1	15
Working connection A2	15
Wrong function	54

**X**

X Direction	36
X-Direction	50
X-Input	34, 42

**Y**

Y-Direction	36, 51
-------------	--------

**Z**

Ziegler-Nichols	60
-----------------	----



## Operating instructions for Intelligent Positioner 1436 cPos

### **Manufacturer's declaration**

**According to the EC Machine Directive 98/37/EC, Appendix II B**

**We hereby declare that the device described in this specification is intended for installation in a machine or application whose commissioning is prohibited until it has been determined that this machine / application conforms to EC Directive 98/37/EC.**

**Handling, assembly and commissioning, in addition to setting and adjustment of the machine must be performed only by authorised specialist staff.**

**GEMÜ®** UNTERNEHMENSBEREICH  
VENTIL-, MESS- UND REGELSYSTEME



GEMÜ Gebr. Müller Apparatebau GmbH & Co. KG · Fritz-Müller-Str. 6-8 · D-74653 Ingelfingen-Criesbach  
Tel. +49(0)7940/123-0 · Telefax +49(0)7940/123-224 · e-mail: [info@gemue.de](mailto:info@gemue.de) · <http://www.gemue.de>

Subject to alteration · 07/2004 · 88243865