

Instruction, Use and Maintenance Manual



PNEUMATIC BALL VALVE

ZVSM

Bardiani Valvole S.p.A.

via G. di Vittorio, 50/52 - 43045 Fornovo di Taro (PR) - Italy

tel. +39 0525 - Fax 0525 3408

bardiani@bardiani.com - www.bardiani.com

MANUAL REVISION	DATE

INDEX

1	Safety, Warning and Mandatory Signs	5
1.1	Operator training	8
2	Safety	9
2.1	General safety warnings	9
3	Technical data	10
4	Checking / Unpacking / Lifting	11
5	Installation	13
6	Operation	31
7	Troubleshooting	32
8	Cleaning	33
9	Disposal	34
10	Maintenance	35
10.1	General maintenance	35
10.2	Scheduled maintenance	36
10.3	Tools useful for Disassembly/Reassembly	37
10.4	Pneumatic Ball Valve ZVSM	38
10.5	Disassembly of the ZVSM	40
A	Disassembly of the BURKERT	41
B	Disassembly of the GEMU	44
C	Disassembly the valve with cylindric connection	45
D	Disassembly the valve with metal plate connection	46
10.6	Assembly of the ZVSM	47
A	Assembly the valve with cylindric connection	48
B	Assembly the valve with metal plate connection	52
C	Assembly Of The Burkert	56
D	Assembly Of The Gemu	59
11	Annexes	60
12	2D diagram ZVSM MACH83-98 GEMU	61
13	2D diagram ZVSM MACH83-98 BRK	62
14	2D diagram ZVSM MACH156 GEMU	63
15	2D diagram ZVSM MACH83-98 GEMU with sheet metal connection	64
16	2D diagram ZVSM MACH83-98 BURKERT with sheet metal connection	65
17	2D diagram ZVSM MACH156 GEMU with sheet metal connection	66
18	Warranty	67
19	Recommendations	68

INTRODUCTION

This "Instruction, Use and Maintenance Manual" has been prepared to provide guidance and recommendations to assist qualified skilled technicians in the understanding, running and maintenance of the Products supplied.

It forms an integral part of the Products supplied and must be read prior to any installation, operation and/or maintenance of all types of valves provided.

This manual must be saved for future reference and be kept readily available at the unit.

With regards to the use of valves compliant with EU Directive 2014/34/UE (ATEX), consultation of a specific manual is mandatory.

The essential characteristics of all types of valves described herein being consistent, the Manufacturer reserves the right to alter and or complement and or update at any time and with no obligation to notify so in writing, the data and or information relevant to the use of the valves described in this "Instruction, Use and Maintenance Manual".







A constantly updated version of this "Instruction, Use and Maintenance Manual" is available at the Manufacturer's website www.bardianivalvole.it.







Under no circumstance shall the Manufacturer be held liable for consequences resulting from failure and or improper use of the instructions contained in this Manual and relating to the installation, operating, maintenance and storage of the products.






All rights reserved.












Full or part reproduction, transfer and or recording of any part of this "Instruction, Use and Maintenance Manual" by all means, whether it be electronic, on hard copy, mechanical or any other means or recording or reuse is strictly prohibited without the prior written consent of the Manufacturer and for any use other than that of the Buyer.

1 Safety, Warning and Mandatory Signs

WARNING SIGNS		
Pictogram	Description	Notes
	WARNING! General	This tells the person in question that the operation described involves (when not performed in accordance with the relative safety regulations) the risk of personal injury.
	WARNING! Hand crushing	Exercise caution in executing the procedure Hand crushing hazard
	WARNING! Heavy loads	Exercise caution in executing the procedure Heavy suspended loads.
	WARNING! Severe burns	Heat emission hazard Very hot surface, risk of severe burns
	WARNING! Risk of explosions	Take Care, risk of explosions
	WARNING Loaded Spring Hazard	Pay attention to the loaded spring during disassembly operations

MANDATORY SIGNS (FOR THE OPERATOR IN CHARGE OF MECHANICAL MAINTENANCE AND THE OPERATOR IN CHARGE OF ASSEMBLY/DISASSEMBLY)		
Pictogram	Description	Notes
	OBLIGATION General	Special instructions must be followed to avoid injury to persons.
	PROTECTIVE GLOVES	Protective gloves must be available for handling objects which could cause hand injuries or when there is the possibility of coming into contact with harmful substances..
	HARD HAT	Hard hats must be available when lifting heavy parts.
	FOOTWEAR	Use safety footwear to protect against injuries caused by falling objects during maintenance operations (particularly when dismantling parts).
	SUITABLE CLOTHING	Suitable clothing such as overalls. It is strictly prohibited to wear clothes with large flapping sleeves and/or other loose items which could easily get caught up in machine parts.
	SAFETY GLASSES	Protective glasses must be available when there is the possibility of contact which harmful substances which could cause eye injuries.

OPERATING SIGNS		
Pictogram	Description	Notes
	PERSONAL PERSONNEL	Dismantling/Assembling and maintenance operations must be carried out by expert technicians only.
	NOTE	Follow the indicated note with care
	ENVIRONMENTAL NOTE	Follow the regulations in force in the country of used governing waste disposal.
	CLAMP	Use of a clamp
	CLAMP WITH SOFT JAWS	Use of a clamp with jaws made from soft material

OPERATING SIGNS		
Pictogram	Description	Notes
	PRESS	Use of a press
	PRESS (release)	Use of a press Gradual release of the pressure force
	ELECTRICAL CONNECTION	Electrical connection to the positioner (consult the relative instruction manual).
	ELECTRICAL DISCONNECTION	Electrical disconnection from positioner (consult the relative instruction manual).
	PNEUMATIC CONNECTION	Connection of the air to the valve.
	PNEUMATIC DISCONNECTION	Disconnection of the air from the valve
	APPLICATION OF FOODSAFE GREASE	Use CIP-FILM grease or similar.
	APPLICATION OF FOODSAFE GREASE	Use FOODLUBE Multi-paste grease or similar.
	APPLICATION OF MULTIPURPOSE GREASE	Use AGIP GREASE MU EP 2 SE or similar.
	THREADLOCK APPLICATION	Use SPEED BOND M500 threadlock or similar.
	OPTIONAL	

1.1 Operator training



All persons who have to work on the valve must be qualified to carry out the relative maintenance tasks. They must be informed as to the possible hazards involved and must observe all the safety instructions set out in this manual. Allow expert personnel only to work on the electrical components.

2 Safety

2.1 General safety warnings

**Intended use**

Bardiani valves have been exclusively for moving fluids.

Prohibited use

The valve must not be used:

- for any operations different to those described under the heading “Intended Use”,
- for handling fluids different to the type specified by the manufacturer;
- for moving fluids at different pressures to those envisaged by the manufacturer and indicated in the valve's technical data.
- Caution: before moving the double-acting actuators, connect both pneumatic connections to the solenoid valves to limit the switching speed and avoid irreversible damage.

Limitations on valve use

It is forbidden to:

- use the valve in a construction configuration different to the one envisaged by the manufacturer.
- use the valve where there is a risk of explosion and/or fire, unless envisaged by the manufacturer (if the valves are certified in accordance with Directive 2014/34/EU, please refer to the ATEX Manual)-;
- integrate other systems and/or equipment which were not considered by the manufacturer during the executive design phase,
- use the valve for purposes other than those specifically envisaged by the manufacturer.

**WARNING!**

The machine may not be used inside premises where there is a potentially explosive atmosphere or risk of fire unless otherwise stated by the manufacturer (in the case of valves certified in accordance with Directive 2014/34/EU please refer to the ATEX Manual).



Pay attention to the loaded spring during disassembly operations



BARDIANI VALVOLE S.p.A. declines all liability for installation, use or maintenance which fails to comply with the indications provided in this manual!

3 Technical data

VALVE DATA	
Maximum seal pressure	See catalogue
Product minimum - maximum temperature	From -20°C to 160°C for applications with air. Depending on the material used for the gaskets and the product
Storage temperature	from -10°C to +25°C
Material in contact with the product	AISI 316L (1.4404). Check the resistance to corrosion in relation to products and detergents
Gasket material in contact with the product	P.T.F.E. Check compatibility with products and detergents

PNEUMATIC ACTUATOR DATA	
Connectors	1/8" (BSP)
Air pressure	From 6bar to 7 bar
Material	AISI 304L
Gaskets material	NBR
Electrical power supply	See Giotto Top



The valve complies with PED 2014/68/EU directive, with special reference to Annex III, Module A, concerning internal manufacturing checks as indicated in the Conformity Assessment Procedures.

Valves with DN equal or smaller than DN25 are not included in compliance with Article 4, paragraph 3.

Valves designed for use with gases, liquefied gases, gases dissolved under pressure, vapours and also those liquids whose vapour pressure at the maximum allowable temperature is greater than 0,5 bar above normal atmospheric pressure (1 013 mbar) are included within the following limits:

- valves with DN between DN32 and DN100 (included) with group 1 fluids;
- valves with DN125 or bigger with group 2 fluids.


The end user must carry out noise assessment testing once the valve has been installed in the plant.

In the event of any doubt, please contact Bardiani Valvole S.p.A..

4 Checking / Unpacking / Lifting


4.1.1. CHECK:

- Check the valve show no signs of damage caused during transport and that it corresponds with the order;
- Check the inside of the valve.



4.1.2. UNPACKING

The valve packaging is made up of cardboard, wood and plastic. The valve is mainly made up of metal materials. The gaskets are usually made from elastomers. Disposal must be in compliance with local legislation.






4.1.3. VALVE LIFTING:

Take care as to the type of valve you are handling. Based on the size there are different lifting procedures.



CAUTION!

Before lifting the valve, make sure there are no disassembled or separate valve parts which could fall off causing injury to persons and damage to the valve.



CAUTION!

The figures above are used purely to represent the methods and procedures for hoisting the valves. Handle the device according to the regulations in force in the country of use.

Bardiani Valvole S.p.A. declines all liability for any damage to things and/or injuries to persons caused by improper and/or incorrect hoisting of the valve.

5 Installation





5.1.1. ELECTRICAL AND PNEUMATIC ENERGY SUPPLY

- Use expert personnel for installation/uninstallation operations;
- Check that the air pressure and quality are correct (see "Technical Data");
- Check the power supply to the positioner is correct (consult the relative instruction manual).

A = Upward movement of the piston


B = Downward movement of the piston

In single acting valves there is only one of the aforementioned commands.




CONFIGURATION			
DN		Gemu	Burkert
10		•	•
15		•	•
20		•	•
25	1/2"	•	•
32		•	•
40	1"1/2	•	•
50	2"	•	•
65	2"1/2	•	•
80	3"	•	•
100	4"	•	•
125		•	
150	6"	•	

5.2.1 BURKERT




Port	CONNECTION
1	Inlet air
2 ₁	Outlet air
2 ₂	Outlet air for double act
3	Exhaust air


5.2.2 Simple act



5.2.3 Double Act



5.2.4 Electrical connections




Warning: Do not remove the display from the positioner with power supply present!

5.2.5 SETTING PARAMETERS

The following parameters are set in the positioner by Bardiani Valvole S.p.A.


Turn on the electrical and pneumatic power supply to the positioner
Press and hold the MENU button until the display bar joins up

1




Use the arrow at the bottom ▲ ▼ to select the ADD.FUNCTION and press ENTER

2



Use the arrow at the bottom to select CUTOFF and activate it by pressing ENTER

3




Press EXIT to return to the MAIN menu

4


Use the arrow at the bottom to select CUTOFF and activate it by pressing ENTER

5




Select Min and press INPUT

6




Press + until 2 appears, and then press OK

7




Move to Max using the buttons ▲ ▼ , then press INPUT,

8



press "-" until 98 appears, then press OK.

9



Press EXIT to return to the MAIN menu

10


5.2.6 CALIBRATION

This procedure must be done every time the positioner is mounted

Move the cursor onto X.TUNE


Use the arrow at the bottom to select the menu.

1




Press RUN until the display bar joins up

2




If you release the RUN button before the bar has joined up, you must press EXIT.

3




If the RUN button is pressed correctly the calibration operation commences automatically.
When TUNE ready appears, press EXIT.

4




Press EXIT again.

5




Press the AUTO button to activate the automatic function.

6




SETTING PARAMETERS
CUTOFF min 2%
CUTOFF Max 98%


5.3.1 GEMU



5.3.2 GEMU Simple Act



5.3.3 GEMU Double Act



5.3.4 Electrical connections


CLAMP	PIN	SIGNAL
X1	1	+24Vdc
X1	3	GND
X3	1	Set point + (4..20 mA)
X3	2	Set point GND

5.3.5 Parameter entry

The following parameters are set in the positioner by Bardiani Valvole S.p.A.


Connect the positioner electrically and pneumatically.

Press



1

Until this appears




Press sequentially



2

Until this appears




Press sequentially



3

Until this appears




Press sequentially





4

Until this appears



Press sequentially




5

Until this appears

```
Return
Superior menu **
```

Press sequentially



6

Until this appears

```
SetFunction
3
```

Press




7

Until this appears

```
PosCtrl
Sets the position
```

Press sequentially



8

Until this appears

```
closeTight 0,0%
Close tight funct
```

Press sequentially



9

Until the cursor is situated before the comma

```
closeTightl 0,0%
← OK ESC
```

Press 2 times



10

Until it appears 2

```
closeTightl  2,01
←      →      +      -
```

Press 2 times



11

Until this appears

```
closeTightl  2,01x
←      OK      ESC
```

Press



12

Until this appears

```
openTight  100,0x
Close tight funct
```

Press sequentially



13

Until the cursor is situated before the comma

```
openTight [10*,01x
←      →      +      -
```

Press




14

Until this appears

```
openTight [ 9*,01x
←      →      +      -
```

Press 2 times




15

Until this appears

```
openTight I 98,0k
←      OK      ESC
```

Press sequentially




16

Until this appears

```
Return
superior menu *
```

Press sequentially




17

Until this appears

```
Return
superior menu *
```

If the valve you are using has an NA cylinder, follow the next steps otherwise go to step 23

Press sequentially




18

Until this appears

```
SetCalibration
4
```

Press sequentially




19

Until this appears

```
Pot  Dir      rise
*****
```

Press sequentially



20

Until this appears




21

Press sequentially




Until this appears



Press

22



Below is a summary of the parameters set

Parameters set for Normally Close valve			Parameters set for Normally Open valve		
2 SET BASIC			2 SET BASIC		
		Help Language GB			Help Language GB
3 SET FUNCTION			3 SET FUNCTION		
	PosCTRL			PosCTRL	
		Close Tight 2%			Close Tight 2%
	PosCTRL			PosCTRL	
		Open Tight 98%			Open Tight 98%
4 SET CALIBRATION					
		Pot Dir Fall			

5.3.6 Calibration

This procedure must be performed each time the positioner is assembled.

Press





23

Until this appears

```
SETUP
*****
```

24

Press sequentially





Until this appears

```
SetBasics
2
```

25

Press sequentially



Until this appears

```
Init Valve
*****
```

26

Press sequentially



Automatic calibration commences. At the end this must appear

```
Init Valve OK
n of valve. Auto
```

27


Press



Until this appears

```
Return
superior menu #
```

Press sequentially




28

Until this appears

```
Return
6
```

Press sequentially



29

Until this appears

```
Mode OFF
operating mode #
```

Press sequentially




30

Until this appears

```
Model Autol
← → + -
```

Press sequentially



31


The positioner is automatic operating mode

**5.3.7. REDUCING THE STRESS TO WHICH THE VALVE IS SUBJECTED:**

- Vibrations;
- Thermal expansion of the piping;
- Excessive welding;
- Overload.

**CAUTION!**

The seal seats may become deformed or cause valve malfunctioning.

**CAUTION!**

Bardiani Valvole S.p.A. declines all liability for any damage to things and/or injuries to persons caused by any failure to correctly follow the installation procedures.



5.3.8. VALVE CONNECTIONS/CONNECTORS:

If the valve is fitted with connectors, you may proceed with installation. Correctly insert the gaskets and tighten the connectors.



5.3.9. WELDING THE VALVE BODY ONTO PIPING:

Remove the body from the rest of the valve before proceeding with welding operations. Please refer to the following pages in this manual.



WARNING!

Hand crushing hazard.



5.3.10. MINIMUM MAINTENANCE CLEARANCES:




Make sure there is enough room to disassemble the valve.

ZVS	
Valve dimension (DN)	A (mm)
10--65	210
65--100	220



CAUTION!

Bardiani Valvole S.p.A. declines all liability for any damage to things and/or injuries to persons caused by any failure to correctly follow the installation procedures.



6 Operation



6.1.1. VALVE INSPECTION BEFORE OPERATION:

- Supply air to the actuator;
- Power the valve (via the control unit);
- Open and close the valve several times;
- Check that the valve works correctly and accurately.

A = Downward movement of the piston



B = Upward movement of the piston

In single acting valves there is only one of the aforementioned commands.



WARNING!

Hand crushing hazard.



7 Troubleshooting



PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
External leak	Worn gasket	Replace the seal
Leaks inside the closed valve caused by normal wear		
External leak	Excessive pressure	Replace with a gasket of a different type of elastomer
	Excessive temperature	
Premature leaks inside the closed valve	Aggressive fluids	Modify the operating conditions
	Too many commands active	
Difficulty opening and closing	Incorrect type of elastomer used for the gaskets	Replace with a gasket of a different type of elastomer
	Incorrect positioning of the actuator	Install the actuator correctly
	Incorrect operation of the actuator	Change from normally open to normally closed or vice versa.
	Impurities in the actuator	Inspection and maintenance of the actuator
	Incorrect valve body positioning	Dismantle and reposition the valve body correctly
positioner malfunction	positioner fault	please refer to the positioner manual.
incorrect valve adjustment		

8 Cleaning



8.1.1. VALVE CLEANING WITH DETERGENTS:

The system in which the valve is installed must be cleaned by expert personnel in observance of the following:

- Abide by the indicated detergent concentration values;
- Observe the instructions provided by the detergent manufacturer.
- Always wear protective safety glasses and gloves.



IMPORTANT!

- Accurately dose detergents to avoid excessive concentration;
- Always rinse thoroughly with clean water after washing.
- Check compatibility of valve materials.





WARNING!

Burns hazard. The valves and piping may be very hot. Wear protective gloves



WARNING

After installing a new or serviced valve, perform an internal washing cycle before using the piping for food liquids. If it there has been any welding work, passivation treatment must be carried out.



EXAMPLE OF INTERNAL WASHING CYCLE (CIP)

Phases	Temperature °C	Washing product
Initial rinse	Environment	Chlorine- and chloride-free water
Washing	70 °C	Caustic soda (NaOH) at 1%
Intermediate rinse	Environment	Chlorine- and chloride-free water
Washing	70 °C	Nitric acid (HNO ₃) at 0.5%
End rinse	Environment	Chlorine- and chloride-free water

Recommended washing product velocity = 2m/s

EN-IST-ZVSM-0426

9 Disposal



At the end of its service life, the device must be recycled in accordance with the legislation in force in the country of valve use.

Any hazardous residues must be taken into consideration and adequately handled.

The valve is made of AISI 316L and AISI 304 stainless steel, elastomers (gaskets), plastic (positioner) and electrical components.

Adhere to the following steps before disconnecting the valve and refer to the heading "General Maintenance".

- make sure the line on which the valve is installed in is not in use
- empty the line on which the valve is installed and clean if necessary
- disconnect the air supply if it is not required during dismantling
- disconnect the valve from the power supply
- remove the valve from the system
- move the valve in observance of the rules set out in the heading "Lifting"
- to dismantle the valve, refer to the heading "Disassembly"

10 Maintenance

10.1 General maintenance



10.1.1. MAINTENANCE PRECAUTIONS

Maintenance operations must be carried out by expert technicians only.



WARNING!

Maintenance operations must be carried out with the line stopped and all utilities (electricity, compressed air) disconnected.





WARNING!

Always discharge the fluid pressure in the valve and piping before disassembling the valve.



WARNING!

Burns hazard. The valves and piping may be very hot. Wear protective gloves





10.1.2. CLEANING AWAY DEPOSITS:

- Thoroughly wash and clean all the valve parts before disassembly;
- Pay attention to any possible detergent or other aggressive fluid deposits (see "Cleaning");
- Always use protective safety glasses and gloves when required.





WARNING!

Hand crushing hazard.



10.1.3. REPLACEMENT OF WORN VALVE PARTS:







Always use original spare parts



10.2 Scheduled maintenance


SCHEDULED MAINTENANCE	VALVE GASKETS	ACTUATOR GASKETS
Preventive	Replace after 12 months	Replace after 24 months
In the event of leaks	Replace at the end of the day	Replace in the event of leaks
Periodical	Check correct operation and that there are no leaks	Check correct operation and that there are no leaks
	Record the actions carried out	Record the actions carried out

10.3 Tools useful for Disassembly/Reassembly

TOOLS	DN10	--	DN100	DN125	DN150
	✓				
	10 (x2) - 13 (x2) - 24			14 - 16 (x2) - 17 (x2) - 24	
	4 - 6				
	5 mm				
	✓				
	✓				


10.4 Pneumatic Ball Valve ZVSM

NO.	DESCRIPTION
21	Cam
25	Screw
36	Plates
137	Screw
143	2-way body
143	3-way body
145	Assembly piece
214	Positioner
234	Screw




10.5 Disassembly of the ZVSM

A




[ZVSM-S-BRK]

B




[ZVSM-S-GEMU]

C



[ZVSM-S-CIL]


D




[ZVSM-S-LAM]

A Disassembly of the BURKERT


1 a




2 a




3 a




4 a




5 a




6 a





7 a




8 a




B Disassembly of the GEMU




C Disassembly the valve with cilyndric connection




D Disassembly the valve with metal plate connection



10.6 Assembly of the ZVSM





[ZVSM-M-CIL]



[ZVSM-M-LAM]




A Assembly the valve with cilyndric connection



[ZVSM-2V-C]



Caution: before moving the double-acting actuators, connect both pneumatic connections to the solenoid valves to limit the switching speed and avoid irreversible damage.





[ZVSM-M-GEMU]

[ZVSM-M-BRK]



[ZVSM-3V-C]





Caution: before moving the double-acting actuators, connect both pneumatic connections to the solenoid valves to limit the switching speed and avoid irreversible damage.





Type "T"





A



B




C




D



A-B
C-D
D-A
B-C





[ZVSM-M-GEMU]



[ZVSM-M-BRK]

B Assembly the valve with metal plate connection





[ZVSM-2V-L]




Caution: before moving the double-acting actuators, connect both pneumatic connections to the solenoid valves to limit the switching speed and avoid irreversible damage.


2-1



[ZVSM-M-GEMU]



[ZVSM-M-BRK]




[ZVSM-3V-L]





Caution: before moving the double-acting actuators, connect both pneumatic connections to the solenoid valves to limit the switching speed and avoid irreversible damage.


2-2




Type "L"





A




B



Type "T"




[ZVSM-M-GEMU]




[ZVSM-M-BRK]

C Assembly Of The Burkert


3-a




4-a




5-a




6-a




7-a





8-a




10-a




9-a





11-a




12-a



13-a




14-a




D Assembly Of The Gemu

3-d



4-d



11 Annexes



EC Declaration of Conformity

EC DECLARATION OF CONFORMITY OF THE MACHINERY

(EC) 2006/42, Annex. II, p. 1 A

BARDIANI VALVOLE S.p.A.

Via G. di Vittorio 50/52 – 43045 Fornovo di Taro (Pr) – Italia

Declares

under its own responsibility that the machine:

Type:	Pneumatic valve
Model:	#####
Serial number:	#####
Function:	Fluid handling
Year of construction:	####
Reference	#####

complies with all relevant provisions of the following EC directive:

(EC) 2006/42 MACHINERY

and also comply with the following EC Directives and Regulations:

(EU) 2014/30 ELECTROMAGNETIC COMPATIBILITY DIRECTIVE (EMC)

(EC) 2023/2006 and subsequent amendments and additions with regard on good manufacturing practices of materials and articles intended to come into contact with food

and the following harmonized standards, rules and / or technical specifications applied:

EN ISO 12100:2010

REGULATION (EC) 1935/2004 and subsequent amendments and additions with regard to steel and elastomers in contact with the product


Fornovo di Taro

##.##.####


Legal Representative

BARDIANI VALVOLE S.p.A.
Via G. di Vittorio 50/52
43045 Fornovo di Taro (Pr) ITALY
Reg. Impr. Parma, C.F.-P.I.V.A. n. 01511810341
R.E.A. Parma n. 159144 • Cap. Soc. € 1.186.800 i.v.

12 2D diagram ZVSM MACH83-98 GEMU


**[ZVSM]**

13 2D diagram ZVSM MACH83-98 BRK




[ZVSM]

14 2D diagram ZVSM MACH156 GEMU


**[ZVSM]**

15 2D diagram ZVSM MACH83-98 GEMU with sheet metal connection




[ZVSM]

16 2D diagram ZVSM MACH83-98 BURKERT with sheet metal connection



17 2D diagram ZVSM MACH156 GEMU with sheet metal connection



[ZVSM]

18 Warranty

1. VALIDITY

Bardiani Valvole's Products are manufactured in compliance with the technical specifications laid out in their "Instruction, Use and Maintenance Manual" and are fully compliant with the directives specifically mentioned in these manuals.

Bardiani Valvole S.p.A. guarantees its own Products against any design and/or construction and/or material defects and/or faults for a period of 12 (twelve) months from the date of delivery.

Notification of any Product defects and/or faults must be sent in writing to Bardiani Valvole S.p.A. within 8 (eight) days from their detection, providing adequate documentation of the defect/fault encountered as evidence.

Services provided in the warranty period shall not result in an extension of the warranty beyond the stipulated 12 (twelve)-month period, as this warranty validity period is to be considered mandatory.

2. CONTENTS OF THE WARRANTY

Notwithstanding and without prejudice to the rights of the Buyer, which may be acknowledged by applicable law, this warranty is to be intended as limited, at the discretion of Bardiani Valvole S.p.A., to the repair and/or replacement of the Product and/or part of the Product and/or its components which is/are found to be defective due to design and/or manufacturing and/or material faults.

In the event of repair and/or replacement of the Product and/or any one of its parts and/or components, any returned item/s shall become the property of Bardiani Valvole S.p.A. and the relative shipping costs shall be charged to Bardiani Valvole S.p.A.

- Bardiani Valvole S.p.A., shall be under no obligation to compensate for any immaterial and/or indirect damages and shall in no way be held liable for consequential damages and/or losses, such as (by way of example only), damages due to loss of business, contracts, opportunities, time, production, profits, goodwill, image etc.
- No retailer or distributor or dealer or agent or representative or employee or person appointed by Bardiani Valvole S.p.A. is authorized to make any amendments and/or integrations and/or extensions to this warranty.

3. WARRANTY EXCLUSIONS

Elastomers are expressly excluded from this warranty.

This warranty does not cover design faults emerging whenever a Product is manufactured by Bardiani Valvole S.p.A. based on designs and/or technical specifications provided by the Buyer.

Moreover this warranty excludes the following:

- faults and/or defects resulting from incorrect and/or unsuitable and/or inadequate transportation of the Product;
- faults and/or defects resulting from failure to comply with the indications laid out in the "Instruction, Use and Maintenance Manual" with regards to installation of the Product or in any event caused by incorrect and/or unsuitable and/or improper installation;
- faults and/or defects resulting from failure to comply with indications laid out in the "Instruction, Use and Maintenance Manual" with regards to use and/or maintenance operations and/or storage of the Product or in any event caused by incorrect and/or unsuitable and/or improper use and/or maintenance operations and/or storage;
- faults and/or defects due to normal wear and tear of the Product and/or its parts and/or its components;
- faults and/or defects in the Product and/or its parts and/or its components for work and/or repairs being carried out by unskilled staff or staff that has not been authorised by Bardiani Valvole S.p.A.;
- faults and/or defects in the Product and/or its parts and/or its components due to it/them being dropped and/or banged and/or dented and/or misused and/or tampering and/or breakage and/or accidents or in any event due to negligence and/or carelessness and/or neglect by the Buyer and in general for any causes not attributable to design and/or manufacturing and/or material defects;
- faults and/or defects in the Product and/or its parts and/or its components caused by other events beyond the control of Bardiani Valvole S.p.A., such as force majeure or unforeseeable circumstances.

19 Recommendations

- 1.** Consultation of the "Instruction, Use and Maintenance Manual" is mandatory prior to the installation, use and maintenance of the products of all Products. All the information, indications, specifications, technical details provided herein are based on test data which the Manufacturer Bardiani Valvole S.p.A. holds to be reliable nevertheless the above is not deemed to be assumed as fully exhaustive inasmuch as not every possible use has been envisaged.
- 2.** All the illustrations and drawings provided are to be intended as indicative and therefore not binding, the illustrations being for presentation purposes only.
- 3.** It is the Buyer's duty to assess the suitability of the products for the use he intends to make of the same prior to placing the order as he/she will take the risks and accept liability in case of incorrect choice and use of the Products.
- 4.** The Manufacturer strongly recommends the Buyer to contact their sales team and request any information that might be needed in relation to the specifications and uses of the Products.
- 5.** The information provided in this manual refers to the standard products manufactured by Bardiani Valvole S.p.A. and therefore cannot be assumed to apply to customized products as well.
- 6.** Bardiani Valvole S.p.A. reserves the right to amend and/or integrate and/or update the data and/or information and/or technical details relative to Products at any time and without prior notice. Please visit the website www.bardiani.com, where the latest updated of the "Instruction, Use and Maintenance Manual" can be found".
- 7.** The content and validity of the warranty covering the Products of Bardiani Valvole S.p.A are dealt with in the relevant section in the "Instruction, Use and Maintenance Manual" which constitutes an integral part of the Products themselves.
- 8.** Bardiani Valvole S.p.A., shall not in any way be held liable for immaterial, indirect and consequential damages, such as (by way of example only), damages or loss of business, contracts, opportunities, time, production, profits, goodwill, image etc..

NOTES

Bardiani Valvole S.p.A.
via G. di Vittorio, 50/52 - 43045 Fornovo di Taro (PR) - Italy
tel. +39 0525 400044 - fax +39 0525 3408
bardiani@bardiani.com - www.bardiani.com